

8-3

OPERATION MANUAL

AUTOMATIC PC BOARD
CHECKER

MODEL APC-1000

KIKUSUI ELECTRONICS CORPORATION

84.6.21.
842643A

Errata Sheet of Instruction Manual

The instruction manual has the following changes.

P-12 ② CPU RESET

Statement added: This will be operated by pressing the machine section ④ PASS as well.

P-15 ④ PASS (indicator and switch)

Statement added: The same operation as the CPU RESET of the controller section will be achieved by pressing this switch.

P-21 INITIAL DATA CREATION PROGRAM OPERATIONS

D: Diode D: Diode (D0000 - D7999)

 Photo diode (D80000 - D9999)

Statement added: For making initial data or learning of all pins short check, see the separate operation manual.

P-48 6.2.2 Inductance Measurement Figure 6.3

 Vs---0.7 Vrms → 0.1 Vrms

P-49 6.2.3 Capacitance Measurement Figure 6.4

 6.2.3.1 Z method

 Vs---0.7 Vrms → 0.1 Vrms

Power Requirements of this Product

Power requirements of this product have been changed and the relevant sections of the Operation Manual should be revised accordingly.

(Revision should be applied to items indicated by a check mark)

Input voltage

The input voltage of this product is _____ VAC,
and the voltage range is _____ to _____ VAC. Use the product within this range only.

Input fuse

The rating of this product's input fuse is _____ A, _____ VAC, and _____.

WARNING

- To avoid electrical shock, always disconnect the AC power cable or turn off the switch on the switchboard before attempting to check or replace the fuse.
- Use a fuse element having a shape, rating, and characteristics suitable for this product. The use of a fuse with a different rating or one that short circuits the fuse holder may result in fire, electric shock, or irreparable damage.

AC power cable

The product is provided with AC power cables described below. If the cable has no power plug, attach a power plug or crimp-style terminals to the cable in accordance with the wire colors specified in the drawing.

WARNING

- The attachment of a power plug or crimp-style terminals must be carried out by qualified personnel.









TABLE OF CONTENTS

	PAGE
1. GENERAL INFORMATION	1
2. SPECIFICATIONS	3
3. PREPARATION	6
3.1 RECEIVING AND HANDLING	6
3.2 CHECKING SUPPLY VOLTAGE	6
3.3 OPERATING TEMPERATURE AND SITING	6
3.4 SETUP PROCEDURE	6
3.4.1 Cable Connections	8
4. CONTROL PANEL DESCRIPTION	12
4.1 DESCRIPTION OF CONTROLLER SECTION PANEL	12
4.2 DESCRIPTION OF MECHANISM SECTION CONTROL PANEL	14
4.3 HOST PROCESSOR PANEL DESCRIPTION	15
5. OPERATING PROCEDURES	16
5.1 OVERVIEW	16
5.1.1 Operation Flowchart	16
5.2 INITIAL OPERATION	17
5.2.1 Host Processor Operations	17
5.2.2 Paper Loading	18
5.2.3 Installing the Pin Board	18
5.2.4 Air Adjustment	18
5.2.5 Controller Section Power On	18
5.3 DESCRIPTION OF OPERATION ITEMS IN MENU	19
5.3.1 Initial Data Creation	19
5.3.2 Reference Data Learning	19
5.3.3 Learned Data Averaging	19
5.3.4 Execution Reference Data Transfer	20
5.3.5 Statistical Data Processing	20
5.3.6 Maintenance	20
5.3.7 Modify	21

842044

	PAGE
5.4 INITIAL DATA CREATION PROGRAM OPERATIONS	21
5.5 REFERENCE DATA LEARNING PROGRAM OPERATIONS	24
5.6 LEARNED DATA AVERAGING PROGRAM OPERATIONS	26
5.7 EXECUTION FILE TRANSFER PROGRAM OPERATIONS	28
5.8 STATISTICAL DATA PROCESSING PROGRAM OPERATIONS	29
5.9 MAINTENANCE PROGRAM OPERATIONS	30
5.10 MODIFY PROGRAM OPERATIONS	32
5.11 PRINT TEST DATA PROGRAM OPERATION	37
5.12 MAINTENANCE AND MODIFY PROGRAM OPERATION	38
5.13 PRINT FORMAT	39
5.14 DAILY OPERATING PROCEDURES	40
5.15 SWITCHING THE CARD MODEL TO BE TESTED	41
5.15.1 Replacing the Pin Board	41
5.15.2 Replacing the Execution Reference Data	41
5.16 WARK FILE CREATING PROCEDURES	42
5.17 MAKING A BACKUP DISKETTE	44
6. THEORY OF OPERATION	46
6.1 BLOCK DIAGRAM	46
6.2 THEORY OF MEASUREMENT	47
6.2.1 Measurement of Tesistance	47
6.2.2 Inductance Measurement	48
6.2.3 Capacitance Measurement	48
6.2.3.1 Z method	49
6.2.3.2 TC method	49
6.3 THREE-TERMINAL GUARD METHOD	50
6.4 MEASUREMENT DELAY	51
6.5 JUDGEMENT CRITERION ERROR	52
7. PIN BOARD DESIGN	53
7.1 CIRCUIT EXAMPLE AND PIN ASSIGNMENTS	53
7.2 PIN ASSIGNMENTS	54
7.3 PIN JIG PARTS AND ASSEMBLY DRAWINGS	56

8/2/08-5

	PAGE
8. NOTES AND PRECAUTIONS	68
8.1 PRECAUTIONS FOR MEASUREMENT	68
8.1.1 Comparison with Other Tester Models	68
8.1.2 Measurement in Composite Circuits	68
8.1.3 Measurement Range	68
8.1.4 Preventing Parts Under Test from Damage or Deterioration	69
8.2 OPERATING PRECAUTIONS	69
8.2.1 Floppy Disk	70
8.2.2 Microprocessor in the Controller Section	70
8.2.3 Print Paper	70
8.2.4 Program Execution Abort and Restart	70
8.3 MECHANISM SECTION AND MULTIPLEXER	70
8.3.1 Press Head Stroke	70
8.3.2 Air Control Valve	70
8.3.3 CUD Discharging	71
8.3.4 Contamination of Contact Pins	71
8.3.5 Emergency Press Head UP Switch	71

842046

1. GENERAL INFORMATION

The APC-1000 is an in-circuit PC board assembly tester intended to increase line inspection productivity for high integration PC board assemblies. It checks for on-board components and circuit patterns in terms of installation error, missing components, defective part characteristics, solder bridges, and discontinuity or short circuit patterns.

The APC-1000 is also capable of making in-circuit GO/NOGO judgements on the ratings of resistors, capacitors or inductors, and on the orientation of semiconductor devices such as transistors and diodes.

The location, part number, and other details of detected errors are printed on the built-in printer.

- 1.1 Three-terminal test method with guard allows precision measurement of the ratings of in-circuit components.
- 1.2 The leaning/averaging feature automatically leans data from up to ten normal board assemblies and averages the data to create reference data file.
- 1.3 Increased operability is ensured by operator-machine dialogue and complete software support.
- 1.4 Reference data file can be saved onto floppy disks. It is easy to access the other data files.
- 1.5 For detected errors, the tester prints out the pertinent part number, measured circuit constant, and location of the part (in one of 10 equal graticles on the board) to lead even an unskilled operator directly to the point in question.
- 1.6 The statistics feature prints the number of inspected boards, that of failed assemblies, and step-number classified failures of a day to provide daily and long-term statistical data.

- 1.7 The reference data file is protected against power off by an internal back-up battery for more than one month. This allows the operator to start job of the day just by switching the system on.

- 1.8 After reference data file is created and debugging is completed, the tester may be placed in the offline mode to execute all test jobs by itself, so that the host computer may be used for other job execution.

842088

2. SPECIFICATIONS

Basic Instrumentation Section

- Testing pins : Typ. 256 pins
Expandable to 512 pins with the optional APC-multiplexer (MPX) unit.
- Test steps : 1024 steps
- Test speed : 20 to 40 ms per step
- Measurable ranges : Resistance: 0.1 Ω to 3.99 M Ω (7 ranges)
Capacitance: 10 PF to 3990 μ F (9 ranges)
Inductance: 10 μ H to 399 mH (5 ranges)
Diode: Constant current of 1 mA is applied across the diode under test to measure its resistance (up to 999 Ω).
Transistor: Same as diodes.
Jumper wire: Less than 10 Ω
Short circuit: Less than 10 Ω
- Criterion for judgement: $\pm 1\%$ to $\pm 99\%$
- Range : Learning: Auto range, with the exception of diodes, transistors, jumper wires, and short circuits, for which fix ranges are used.
Comparison: Fixed range
- Instrumentation delay : Max. 750 ms at 50 ms intervals for 16 different values: i.e. 0, 50, 100, 150, 200,.....
..., 700, 750 ms.
- Multiplexer relay : Dry relay (life: 1000 million operations)
- Reference data file back-up period: 30 days

842089

CPU (host CPU: UNIVAC UP10E Model 10)

Display : 12" green display

Floppy disk drive : Two drives for 5-1/4 inch double-sided, double-density diskettes, double-Track diskettes.

Keyboard : Full keyboard plus function keyboard

Interface : RS-232C, Centronix, or parallel I/F

Printer

Print format : 24 characters per line on 5 x 7 dot matrix

Print form : Roll paper with the diameter of 50 mm and width of 70 mm

Self test feature : Provided.

Mechanism Section

Air press: Air cylinder: Inner diameter: 75 mm
Stroke: 150 mm
Pressure: Approx. 220 kg (air input: 5 kg/cm²)
Capacity: Approx. 9 liters for each operation

Air inlet nipple: 1/4 inch
Air input: 4 to 10 kg/cm²

Test table: Measurable PC board size: (W)450 x (D)350 mm
Connector: Six Amphenor 50-pin connectors (57-40500)

Power Supply

Power requirements : 100 VAC ±10%, 50/60 Hz
Approx. 170 VA (except for service outlets)

FUSE : Main Frame 10A
MPX Unit 3A
I/F Board 2A

250278

Dimensions and Weight

Outer dimensions (max.): Electrical section:
(W)600 x (H)1060 x (D)920 mm
Mechanism section:
(W)720 x (H)1610 x (D)920 mm

Weight : Mechanism section: Approx. 208 kg
Electrical section: Approx. 67 kg
CPU: Approx. 15 kg

Environmental Conditions

Operating temperature : 5 to 35 °C
Operating humidity : Not more than 75% RH

Accessories

Operation Manual	1
PCB Pin Board (clear plastic board with 5 mm t)	1
PCB Push Board (universal board clamp)	1
Push Rod (PC board pushing rod), Long and Short Type	10 each
Connector Bracket (connector mount)	1
Bracket (pin board mount)	1
Collar (10 ϕ x 101.5 mm)	10
50-pin connector (57-40500)	6
Test Program Library (supplied on diskettes)	1 set
Roll paper for printer (50 x 70 mm)	1 roll

84. 6. 21
842051

3. PREPARATION

3.1 RECEIVING AND HANDLING

The tester is carefully tested in both mechanical and electrical terms before packed by experienced workmen. Immediately upon receipt of the tester, an examination should be made for any damage sustained in transit. If injury or rough handling is evident, immediately notify your dealer.

3.2 CHECKING SUPPLY VOLTAGE

The tester is designed to operate on a line voltage of 100 VAC $\pm 10\%$, 50/60 Hz. To ensure trouble-free operation, use the proper line voltage without contaminated by line noise.

3.3 OPERATING TEMPERATURE AND SITING

To maintain the initial performance of the tester for an extended period of time, be sure to use the tester in the specified operating temperature and humidity ranges. The tester should be installed in a place where it will not be exposed to excessive dust or oil-born air.

3.4 SETUP PROCEDURE

The APC-1000 Tester consists of mechanism and electrical sections, with the host processor placed on the electrical section table, as shown in Figure 3.1. The rear interconnection cables have extra lengths, so that the electrical section may be sited apart from the mechanism section.

Figure 3.2 illustrates the cable connections on the rear of the tester. While referring to this figure, establish rear cable connections using the cables listed in the following subsection.

The external view of the AP-1000 tester is shown in Figure 3.3.




Figure 3.1 AP-1000 Automatic PC Board Assembly Tester

842053

3.4.1 Cable Connections

While referring to Figure 3.2, establish all the rear cable connections for the tester as instructed below.

Note. Cables marked with an asterisk (*) are factory connected.

- Rear bottom left of controller: AC power cable --- to a wall outlet
- POWER UNIT/OUT AC100 : 8-pin round connector --- to the rear bottom left connector on the mechanism section (*).
- POWER UNIT/IN AC100 : 8-pin round connector --- to the rear bottom left connector on the controller.
- POWER UNIT/FOR CONTROL : 8-pin round connector --- to CONTROL UNIT/DC IN (*)
- POWER UNIT/FOR MEAS : 8-pin round connector --- to MEASUREMENT UNIT/POWER
- POWER UNIT/FOR PRINTER : 8-pin round connector --- to PRINTER I/F
- POWER UNIT/AC 100 (service outlet) --- accepts the power cable of the host processor.
- CONTROL UNIT/MEAS IN : 50-pin connector --- to MEASUREMENT UNIT/CONT-OUT.
- CONTROL UNIT/MEAS OUT : 50-pin connector --- to MEASUREMENT UNIT/CONT IN.
- CONTROL UNIT/PRT IN : 50-pin connector --- to PRINTER I/F (upper).
- CONTROL UNIT/PRT OUT : 50-pin connector --- to MEASUREMENT (lower).

8X2054

- CONTROL UNIT/OUT : 50-pin connector --- to MPX UNIT (left)/CONT I/O A
- CONTROL UNIT/UP10 : 50-pin connector --- to host CPU/ PARALLEL I/O
- MPX UNIT (left)/CONT I/O B : 50-pin connector --- to MPX UNIT (right)/CONT I/O A
- MPX UNIT (left)/SIG : 4-pin connector --- MEASUREMENT UNIT/SIG A (*)
- MEASUREMENT UNIT/SIG B : 4-pin connector --- MPX UNIT (right)/SIG (*)

Mechanism section rear bottom left/service outlets --- accept power cord of PRINTER I/F (*)
 MPX UNIT (left) (*)
 MPX UNIT (right) (*)

Mechanism section rear bottom left/AIR input --- accepts an external air source.

Host CPU Keyboard --- rear of host CPU/KEYBOARD connector

MPX UNIT (left)/1-6 Pin board, CONNECTOR BRACKET/1-6 (*)
 ┌────────── 50-pin cable ─────────┐ (See Figure 7.2.)

MPX UNIT (right)/7-12 Pin board, CONNECTOR BRACKET/7-12 (*)
 ┌────────── 50-pin cable ─────────┐ (See Figure 7.2.)

The MPX UNIT (right) is an optional multiplexer unit required when additional testing pins are to be used.

842055




Figure 3.2 Rear cable connections

1-5678




Figure 3.3 Outer dimensions

20257

4. CONTROL PANEL DESCRIPTION

4.1 DESCRIPTION OF CONTROLLER SECTION PANEL

See Figure 4.1 Controller section panel.

- ① POWER : System's main power switch. When set to the upward position, the system is powered and the associated pilot lamp comes on.
- ② CPU RESET : Resets the CPU within the controller to suspend test execution. Operation of this switch raises the press head and restores the tester from online into offline mode.
- ③ CNT CLEAR : Statistical data, such as the number of tested cards, that of defective cards, step-number classified defect count, and so forth, is stored in the memory of the controller under battery back-up. This switch is used to clear all those statistical data.
- ④

ON R	ON B
---------	---------

 : Used to switch between online and offline modes. When the tester is powered up, the indicators in this switch are both left off, indicating the tester's controller section is in the offline mode to its host processor. To place the controller in the online mode, press this switch. The

ON R

 indicator first comes on, then the

ON B

 indicator comes on when the learning/maintenance program execution is completed. The controller is now placed in the online mode. To return the tester in the offline mode, press this switch again; both of the indicators will go off. If the controller is communicating with the host processor when the switch is operated, the

ON R

 indicator goes off but the

ON R

 indicator remains on until the communication is completed. The

ON R

 denotes online ready, and

ON B

 denotes online busy.

842058

- ⑤ ALL PRINT : The printer contained in the mechanism section prints the details of failed test results. If the ALL PRINT switch is pressed, all of the false data is dumped on the printer (ALL PRINT indicator comes on).




Figure 4.1 Controller section panel

842059

4.2 DESCRIPTION OF MECHANISM SECTION CONTROL PANEL

See Figure 4.2




Figure 4.2 Mechanism section control panel

- ① TEST switches : Simultaneously press these switches to start test execution after placing the card to be tested on the pin board. If only either of these switches is operated, the press head will not be lowered. Press and hold both switches until the press head is completely lowered to the card under test (CUD). If either of the switches is released when the press head is being lowered, the head will be raised again.
- ② Printer : Prints test data.

8422060

- ③ Print form : Roll paper of 70 mm wide and 50 mm ϕ used for the printer.
- ④ PASS (indicator): When illuminated, indicates the test is passed (good). Once this indicator comes on, it remains on until the next test sequence is initiated.
- ⑤ RESET switch : Used to reset printer error.
- ⑥ FEED switch : Used to feed print form.
The printer's self check print can be initiated by the following operations:

RESET on → FEED on → FEED off

4.3 HOST PROCESSOR PANEL DESCRIPTION

The AP-1000 Tester uses the UNIVAC UP10E Model 10 Processor with two integrated floppy disk drives as its host CPU. For more details of the processor, see the separate user's manual.

When the Model 10 Processor is to be used as the host CPU for the APC-1000 Tester, only the rear POWER switch, front BRIGHT control, floppy disk drives A and B, and keyboard are used for test execution.

The supplied system diskette should be placed in the floppy disk drive A, while the APC-1000 Automatic PC Board Checker Work File diskette should be placed in drive B. Be sure to turn the processor power on before inserting these diskettes into its drives.

To start up the host processor, simultaneously press the CTRL and RESET keys on the keyboard after placing the diskettes in the respective drives. A menu will appear on the video monitor.

842061

5. OPERATING PROCEDURES

5.1 OVERVIEW

5.1.1 Operation Flowchart




Figure 5.1 Operation flowchart

842062

The operation menu contains seven choices of operation programs: i.e. initial data creation, reference data learning, learned data averaging, averaged data transfer, statistical processing, maintenance, and correction.

A variety of command sets are available for each of these operation programs to assist the operator in test execution.

5.2 INITIAL OPERATION

5.2.1 Host Processor Operations

After making sure that no diskette is in either of the drives, set the host processor's rear POWER switch to ON.

Insert the supplied APC-1000 Automatic PC Board Checker SYSTEM diskette into drive A, and the WORK FILE diskette into drive B, then simultaneously press the CTRL and RESET keys on the keyboard. The host processor will start up and the menu will appear on the video monitor.

All the preparatory operations for the host processor are now completed.


```
APC-1000  AUTOMATIC PC BOARD CHECKER (Ver 1.4)
***** MENU *****
*
* FUNCTION 1 ----- INPUT INITIAL DATA *
* FUNCTION 2 ----- LEARN DATA *
* FUNCTION 3 ----- AVERAGE OF LEARN DATA *
* FUNCTION 4 ----- TRANSFER OF EXC FILE *
* FUNCTION 5 ----- STATISTICS *
* FUNCTION 6 ----- MAINTENANCE *
* FUNCTION 7 ----- MODIFY *
* FUNCTION 8 ----- PRINT TEST DATA *
* FUNCTION 9 ----- MAINTENANCE & MODIFY *
*
*****
```

THEN PRESS FUNCTION KEY

842063

5.2.2 Paper Loading

Open the paper compartment lid on the printer, and install the accessory roll paper (70 mm wide, 50 mm ϕ) on the paper holder in the compartment after inserting the accessory roll paper shaft in the center of the roll.



Insert the leading edge of the paper into the paper guide. After switching the main power on, thread the paper as shown in the above figure using the **FEED** switch.

5.2.3 Installing the Pin Board

Install the pin board (which has been designed according to later section) on the mechanism section deck. Place a normal card or card to be tested on the pin board, as needed.

5.2.4 Air Adjustment

Adjust the air pressure to approximately 3 kg/cm². For the details of air pressure adjustment see the description of setup procedures.

5.2.5 Controller Section Power On

Set the main POWER switch on the controller section to ON. Set the

ON	ON
R	B

 (online/offline) switch (4) described in section 4.1 to online.

The ALL PRINT switch/indicator (5) on the controller section should be off, in which case only false test data is printed out.

As described in subsection 5.2.2, thread the print paper through

8K 2064

the printer using the **FEED** switch. Execute printer's self check print as described in section 4.2.

Now all the required preliminary operations are completed.

Select the desired operation item out of the menu displayed on the monitor by operating the pertinent function key or numeric key out of **PF1** through **PF7** or **1** through **7**.

The following section describes each of the operation items contained in the menu.

5.3 DESCRIPTION OF OPERATION ITEMS IN MENU

5.3.1 Initial Data Creation (Select with **PF1**.)

This program executes the initial data creation program for reference data learning, in which the operator types in part and pin number information for sequential steps which are automatically generated.

While the GND pin may or may not be specified at operator's option, it may be specified to reduce stray impedance in the circuit under test and to increase measurement accuracy.

For the details of specification procedure, see chapter 6 Theory of Operation.

Step numbers are programmable between 1 and 1024.

5.3.2 Reference Data Learning (Select with **PF2**.)

This operation automatically learns reference data from up to ten normal cards in auto range, in the order of the steps generated by the initial data creation program. The learned data is stored on the WORK FILE diskette (which is placed in Drive A in the host processor) to which an optional file name is assigned.

5.3.3 Learned Data Averaging (Select with **PF3**.)

This program averages the learned file data according to the number of normal cards used for learning.

In the course of averaging, the operator can monitor the maximum,

842065

minimum, and averaged values of learned data at each step. If he finds a file which seems to be inadequate for averaging, he may delete that file and then re-execute averaging again.

The averaged data file is stored on a diskette as an execution reference data file.

5.3.4 Execution Reference Data Transfer (Select with PF4 .)

This program transfers the execution reference data stored in the file from the host processor to the controller section of the tester.

The tester becomes ready for test execution when it is placed in the offline mode after data transfer is completed. Place the card to be tested on the pin board, then press the TEST switches (described in section 4.2) simultaneously to start test execution. If the test is passed, the PASS indicator (4) will come on. If it failed, the test result will be printed out on the printer (2). The reference data transferred to the controller section remains intact against power off for more than one month.

5.3.5 Statistical Data Processing (Select with PF5 .)

This program performs statistical processings on test data. It prints the number of tested cards, that of failed cards, step-number classified failure count, and other information to allow for daily or long-term statistical data processing.

5.3.6 Maintenance (Select with PF6 .)

This program display the contents of any step of the execution reference data or to execute any test step for a normal card or card to be tested which is placed on the tester's pin board and display the result of measurement for that step. The maintenance program is used primarily for debugging of the execution reference data program or of the test program, and may be controlled interactively from the host processor.

842066

5.3.7 Modify (Select with PF7.)

This program allows the operator to correct or update reference values in the execution reference data or the range of judgement criteria (default assumption is $\pm 10\%$), or to append on-board part location specification (X-Y coordinate) or measurement delay time setup. All operations can be done step-by-step from the display of the host processor.

The following sections describe the operating procedures for each of the programs described just above.

5.4 INITIAL DATA CREATION PROGRAM OPERATIONS

Press the function key PF1; the display will provide the following image. Type in the type of the part to be tested, part number, positive pin number, negative pin number, and GND pin number for the respective steps (up to 1024) which automatically generate. (For the details of GND pin number specification, see section 6.2 THREE TERMINAL GUARD TECHNIQUE.)

***** INPUT INITIAL DATA *****

<u>9999</u> ,	<u>X9999</u> ,	<u>999</u> ,	<u>999</u> ,	<u>999</u> (CR)
1	2 3	4	5	6 7

1: STEP NUMBER GENERATE AUTOMATICALLY

2: KIND OF PARTS

R: RESISTOR	T: TRANSISTOR
L: COIL	D: DIODE
C: CONDENSER	J: JUMPER
S: SHORT	

E: END OF INPUT #: INPUT MODIFY

3: PARTS NUMBER	0-9999
4: (+) PIN NUMBER	0-511 (MAX)
5: (-) PIN NUMBER	0-511 (MAX)
6: GND PIN NUMBER	0-511 (MAX)
7: PRESS (CR) [RETURN] KEY AFTER KEY-IN DATA	

THEN PRESS (CR) [RETURN] KEY TO NEXT !!

842067

Press the **RETURN** key; the display will provide the following information:

***** LEARN DATA *****

KEY-IN FILE NAME (MAX 6 CHARACTERS)

DSSA2	.DAT	A200	.DAT	DSSA22	.DAT	CK512	.DAT
JALC55	.DAT	SH01A	.DAT	DEMO	.DAT	ABC	.DAT
TEST99	.DAT						

FILE NAME

If a file name which is not in the filename listing on the display is typed in (followed by **RETURN** key operation), file creation will be started with step 1.

STEP	PARTS	+PIN	-PIN	GND.PIN	INPUT DATA
0001,					

File name specification should not include the attribute ".DAT". In this case key-in data of, say, "R15," is shown as "R0015". If "23," is typed in for a +pin number, it will be displayed as "023". If only a -pin number is specified with no GND pin number specified, type **24** **RETURN**. If you typed "24,", delete the comma "," using the **BS** key, then operate the **RETURN** key again.

When completing pin information entry, press the **E** key. The display will show the message "DATA SAVED B:A.DAT", then return to the menu image. If **#** is pressed instead of **E**, the display will show an initial data update menu.

If one of the file names listed in the filename listing on the display is typed in, the file is either newly created or the successive part, file creation starts with the successive step number. The following shows an example:

842068

KEY-IN FILE NAME < MAX 6 CHARACTERS >

DSSA2	.DAT	A200	.DAT	DSSA22	.DAT	CK512	.DAT
JALC55	.DAT	SH01A	.DAT	DEMO	.DAT	ABC	.DAT
TEST99	.DAT						

FILE NAME DSSA2

GENERATE from FIRST STEP ? (Y/N)

If "N" is typed in, file creation starts with the successive step number, as shown below:

STEP	PARTS	+PIN	-PIN	GND.PIN	INPUT DATA
0001,					

The following shows a display example for initial data creation process:

STEP	PARTS	+PIN	-PIN	GND.PIN	INPUT DATA
0001,	R0001,	001,	002,	003	0001,R0001,001,002,003<CR>
0002,	L0001,	004,	005,	006	0002,L0001,004,005,006<CR>
0003,	C0001,	007,	008,	009	0003,C0001,007,008,009<CR>
0004,	D0001,	010,	011,	012	0004,D0001,010,011,012<CR>
0005,					

The following shows the initial data update menu obtained by operating the key. This allows initial data display and update.

***** MODIFY INITIAL DATA *****

D: DISPLAY 20 LINES FROM SPECIFY STEP
C: CHANGE OF SPECIFY STEP
E: END OF MODIFY
R: REPEAT OF INPUT DATA

KEY-IN COMMAND & STEP NO.(ex. D1 <CR>) D100

If you typed , the machine will provide the following information:

842069

STEP	PARTS	+PIN	-PIN	GND.PIN	INPUT DATA
0100,	D0009,	041,	034,	035	
0101,	D0010,	017,	036		
0102,	D0011,	041,	040,	039	
0103,	D0012,	036,	039,	040	
0104,	D0013,	000,	000		
0105,	D0014,	050,	057,	055	
0106,	D0015,	043,	046		
0107,	D0016,	055,	051,	056	
0108,	D0017,	055,	047,	046	
0109,	D0018,	052,	044,	051	
0110,	D0019,	047,	059,	060	
0111,	D0020,	000,	000		
0112,	D0021,	017,	030,	072	
0113,	T0001,	009,	000,	004	
0114,	T0002,	012,	013,	004	
0115,	T0003,	069,	060,	017	
0116,	T0004,	035,	037		
0117,	T0005,	039,	030		
0118,	T0006,	063,	067,	066	
0119,	T0007,	064,	065,	067	

If you wish to do _____ what? _____ again, press the _____ which? _____ key, then type in the step number.

If you wish to update initial data, operate .

The machine will show the following:

STEP	PARTS	+PIN	-PIN	GND.PIN	INPUT DATA
0100,	D0009,	041,	034,	035	
0100,					

For the items requiring no update, type in a comma (,). For the item requiring update, type in the replacement data, then enter a comma (,).

5.5 REFERENCE DATA LEARNING PROGRAM OPERATIONS

Press the function key PF2; the display will show the filename listing for initial data creation. Specify the pertinent file name out of the listing.

The machine learns reference data from normal cards according to the selected file name.

842070

***** LEARN_DATA *****

KEY-IN FILE NAME (MAX 6 CHARACTERS)

D66A2	.DAT	A200	.DAT	D66A22	.DAT	CK512	.DAT
JALC55	.DAT	SH01A	.DAT	DEMO	.DAT	ABC	.DAT
TEST99	.DAT						

FILE NAME

When the file name (except the attribute .DAT) is typed in, the display will show the following message. After making sure the controller is in the online mode, press the two TEST switches simultaneously to lower the press head.

CONTROLLER NOT READY !!

When data learning is initiated, the learned data will be shown on the display in the order of step numbers. Learning will continue to the last step of the initial data file. When learning from one normal card is completed, the following messages will appear on the display.

If learning is to be continued for another card, press Y.

If you typed N, the machine will proceed with execution file (.EXC file) creation.

LEARN DATA 01 SHEET END

CONTINUE LEARN DATA ? (Y/N)

When the execution file has been created, control will return to the menu.

84207/

5.6 LEARNED DATA AVERAGING PROGRAM OPERATIONS

Press the function key PF3; the following list of learned data file names will appear on the display.

While each file name in the listing is attached with 01.DSB through 10.DSB, depending on the card number from which data has been learned, type in only the file name (as shown in the example) when specifying the file to be averaged (the attached are the attributes).

```
***** AVERAGE OF LEARN DATA *****
KEY-IN FILE NAME ( MAX 6 CHARACTERS )
DEMO01 .DSB      DEMO02 .DSB

[example]
XXXXXXXX01.DSB ----> XXXXXXX
FILE NAME DEMO
FILE NAME       : B:DEMO01.DSB
LEARN FILE COUNT : 2
AVERAGE LEARN DATA ? (Y/N) Y

LOADING FILE !!   B:DEMO01.DSB
LOADING FILE !!   B:DEMO02.DSB
SAVED FILE   !!   B:DEMO.AVE
```

The maximum, minimum, and averaged values of the averaged file can be monitored on the screen.

The maximum, minimum, and averaged values of the averaged file can be monitored on the screen.

DISPLAY AVERAGE FILE ? (Y/N)

***** LEARN DATA. MAX/MIN/AVE *****

FILE NAME B:DEMO.AVE

[] IS FILE NUMBER

STEP	MAX	MIN	AVE
0001	499. o [1]	499. o [1]	499. o
0002	1.22nF [2]	1.20nF [1]	1.21nF
0003	1.22nF [1]	1.13nF [2]	1.17nF
0004	1.12nF [1]	1.07nF [2]	1.09nF
0005	1.23nF [2]	1.22nF [1]	1.22nF
0006	258. o [1]	254. o [2]	256. o
0007	413. o [1]	404. o [2]	408. o
0008	445. o [1]	435. o [2]	440. o
0009	476. o [1]	466. o [2]	471. o
0010	502. o [1]	498. o [2]	500. o
0011	499. o [1]	499. o [1]	499. o
0012	499. o [1]	498. o [2]	498. o
0013	499. o [2]	498. o [1]	498. o
0014	500. o [2]	499. o [1]	499. o
0015	499. o [1]	498. o [2]	498. o
0016	498. o [1]	498. o [1]	498. o
0017	9.99 o [1]	9.99 o [1]	9.99 o
0018	9.99 o [1]	9.99 o [1]	9.99 o
0019	9.99 o [1]	9.99 o [1]	9.99 o
0020	9.99 o [1]	9.99 o [1]	9.99 o

DISPLAY NEXT 20 STEPS ? (Y/N)

842073

26-1

If "N" is typed in for the question "Do you wish the next 20 steps to be displayed?", _____ what? _____ will be displayed in an interactive manner, with the cursor repositioned.

If an inadequate file is found as a result of averaging, delete that file number (01-10). The machine will return to averaging process with the deleted file excluded from averaging. The maximum, minimum, and averaged values of the resulting averaged data can also be monitored on the screen.

If there is no file to be deleted for averaging, type in "N".

The machine will then ask whether the execution data file is to be created from the averaged file.

The execution file can be created by typing in "Y". If update of tolerance data, entry of part location information, measurement delay setup, or reference data change is required, use the update menu.

The machine will then ask whether or not the main file name learning file (XXXX01.DSB to XXXX10.DSB) and the max./min./average file (XXXX.AVE) are to be simultaneously deleted.

Since each diskette can store up to four models, it is advisable that those files be deleted as far as possible.

If all the files are to be left undeleted, it is advisable that each diskette be reserved for only one model.

```
DELETE FILE ? (FILE No. or N )
GENERATE EXC FILE ? (Y/N) Y
DELETE MEDIUM FILES (.DSB. AVE ) ? (Y/N)
```

5.7 EXECUTION FILE TRANSFER PROGRAM OPERATIONS

Press the function key PF4; a listing of the execution data file names will appear on the display. Type in the file name (except for the .EXC) to be transferred.

842079

***** TRANSFER EXC FILE *****

. KEY-IN FILE NAME (MAX 6 CHARATERS)

A200	.EXC	DEM01	.EXC	DEM02	.EXC	CK512	.EXC
CK256	.EXC	TEST99	.EXC	DSSA2	.EXC	DEMO	.EXC
ABC	.EXC	K	.EXC				

FILE NAME

Be sure to type in the correct file name. Also make sure the controller is in the online mode.

During transfer busy, the message "EXECUTION PROGRAM TRANSFER BUSY" will appear on the display. It will take some three minutes to transfer a file comprised of some 200 steps.

When data transfer is completed, control will return to the main menu.

5.8 STATISTICAL DATA PROCESSING PROGRAM OPERATIONS

Press the function key PF5; when the controller is in the online mode, the following image will appear on the display and the statistical data will be printed on the printer using the format shown in section 5.11.

***** STATISTICS *****

PRINTING DATA TO PRINTER !!

WAIT A MINUTE

When print operation is completed, the same data will be shown on the display as well.

842075

***** STATISTICS *****

TEST NUMBERS 3 SHEET
FAIL NUMBERS 3 SHEET

PRESS (CR) KEY

***** FAIL DETAILS *****

STEP NO.	FAIL NUMBERS
0002	3
0003	3
0004	3
0005	3
0006	3
0007	2
0008	2
0010	1
0017	3
0018	3

PRESS (CR) KEY

If the RETURN key is pressed, control will return to the main menu.

5.9 MAINTENANCE PROGRAM OPERATIONS

Press the function key PF6; the following image will appear on the display. Type in the execution file name (except for .EXC).

Figure: When the file name is type in, the file is loaded.

***** MAINTENANCE *****

KEY-IN FILE NAME (MAX 6 CHARACTERS)

A200	.EXC	DEM01	.EXC	DEM02	.EXC	CK512	.EXC
CK256	.EXC	TEST99	.EXC	DSSA2	.EXC	DEMO	.EXC
ABC	.EXC	K	.EXC				

FILE NAME DEMO

LOADING DEMO !!

842076

CONTROLLER NOT READY!!

When this message appears, make sure the controller is in the online mode, place the card to be tested on the pin board, then press and hold the **TEST** switches simultaneously until the press head is completely lowered to the card.

The maintenance menu shown below allows the operator to display 20 lines beginning with any step (e.g. D1), execute any step of the program (e.g. T1), proceed with the next step (e.g. N), repeat the same step (e.g. R), or terminate the maintenance program (E).

When _____ what? _____ is executed, the measured values will be shown on the monitor, as shown in the following example:

***** MAINTENANCE MENU *****

D: DISPLAY 20 LINES FROM SPECIFY STEP
T: EXECUTE OF SPECIFY STEP
N: ADVANCE NEXT STEP
R: REPEAT SAME STEP
E: END

KEY-IN COMMAND & STEP No. (ex. D1 <CR>) D1 (If D1 is typed in:)

0001	R0001, 252, 254, ,499. o, 10%, 3,00, 0, 0
0002	C0201, 253, 254, 114,1.21nF, 10%, 4,00, 0, 0
0003	C0202, 255, 254, 112,1.17nF, 10%, 4,00, 0, 0
0004	C0213, 083, 078, 103,1.09nF, 10%, 4,00, 0, 0
0005	C0232, 174, 173, ,1.22nF, 10%, 4,00, 0, 0
0006	D0201, 226, 068, 254,256. o, 10%, 3,00, 0, 0
0007	D0202, 226, 067, 254,400. o, 10%, 3,00, 0, 0
0008	T0201, 059, 068, 254,440. o, 10%, 3,00, 0, 0
0009	T0202, 064, 241, 254,471. o, 10%, 3,00, 0, 0
0010	T0202, 064, 067, 254,500. o, 10%, 3,00, 0, 0
0011	R0213, 060, 040, ,499. o, 10%, 3,00, 0, 0
0012	R0218, 035, 062, ,498. o, 10%, 3,00, 0, 0
0013	R0230, 008, 007, 009,498. o, 10%, 3,00, 0, 0
0014	R0242, 078, 000, ,499. o, 10%, 3,00, 0, 0
0015	R0270, 114, 113, 112,498. o, 10%, 3,00, 0, 0
0016	R2127, 201, 170, 203,498. o, 10%, 3,00, 0, 0
0017	J0201, 001, 002, ,9.99 o, 10%, 1,00, 0, 0
0018	J0202, 002, 003, ,9.99 o, 10%, 1,00, 0, 0
0019	S1021, 003, 022, ,9.99 o, 10%, 1,00, 0, 0
0020	S1022, 022, 028, ,9.99 o, 10%, 1,00, 0, 0

64 02 79

***** MAINTENANCE MENU *****

D: DISPLAY 20 LINES FROM SPECIFY STEP
T: EXECUTE OF SPECIFY STEP
N: ADVANCE NEXT STEP
R: REPEAT SAME STEP
E: END

KEY-IN COMMAND & STEP No. (ex. D1 <CR>) T1 (IF T1 is typed in:)

0001 R0001, 252, 254, ,499. o, 10%, 3,00, 0, 0
ACTUAL VALUE = 497. o

***** MAINTENANCE MENU *****

D: DISPLAY 20 LINES FROM SPECIFY STEP
T: EXECUTE OF SPECIFY STEP
N: ADVANCE NEXT STEP
R: REPEAT SAME STEP
E: END

KEY-IN COMMAND & STEP No. (ex. D1 <CR>) N (IF N is typed in:)

0002 C0201, 253, 254, 114,1.21nF, 10%, 4,00, 0, 0
ACTUAL VALUE = 9.990F

***** MAINTENANCE MENU *****

D: DISPLAY 20 LINES FROM SPECIFY STEP
T: EXECUTE OF SPECIFY STEP
N: ADVANCE NEXT STEP
R: REPEAT SAME STEP
E: END

KEY-IN COMMAND & STEP No. (ex. D1 <CR>) R (IF R is typed in:)

0002 C0201, 253, 254, 114,1.21nF, 10%, 4,00, 0, 0
ACTUAL VALUE = 9.990F

5.10 MODIFY PROGRAM OPERATIONS

Press the function key PF7; the following execution data filename listing will appear on the display. Type in the file name (except for .EXC) to be corrected.

When the selected file is loaded, the correction menu will appear on the display. The correction menu allows the operator to display 20 lines beginning with any step (e.g. D1), insert a line at any

step (e.g. I15), delete any step (e.g. K20), update any step (e.g. C13), correct the tolerance of a part type (e.g. A), store the file after correction is completed (e.g. E), or complete insertion operation (e.g. E).

The following shows an operation example:

***** MODIFY PROGRAM *****

KEY-IN FILE NAME (MAX 6 CHARACTERS)

A200	.EXC	DEMO1	.EXC	DEMO2	.EXC	CK512	.EXC
CK256	.EXC	TEST99	.EXC	DSSA2	.EXC	DEMO	.EXC
ABC	.EXC	K	.EXC				

FILE NAME

*** MODIFY MENU ***

D: DISPLAY 20 LINES FROM SPECIFY STEP
 I: INSERT SPECIFY STEP
 K: DELETE SPECIFY STEP
 C: CHANGE SPECIFY STEP
 A: ERROR SET OF EACH PART
 E: SAVE MODIFIED FILE or END OF INSERT
 KEY-IN COMMAND & STEP No. (ex. D1 (CR)) ? D1

(If D1 is typed in:)

0001	R0001	001	002	003	499.	o	10%	3	00	0	0
0002	L0001	004	005	006	0.62mH	10%	4	00	0	0	0
0003	C0001	007	008	009	1.02nF	10%	4	00	0	0	0
0004	D0001	010	011	012	254.	o	10%	3	00	0	0
0005	R0001	005	006	007	401.	o	10%	3	00	0	0
0006	L0001	008	009	010	0.55mH	10%	4	00	0	0	0
0007	C0001	011	012	013	1.22nF	10%	4	00	0	0	0
0008	D0001	014	015	016	252.	o	10%	3	00	0	0

1	2	3	4	5	6	7	8	9	10	11

- | | | | |
|----|---------------|----|-----------------|
| 1 | Step No. | 2 | Part No. |
| 3 | +Pin No. | 4 | -Pin No. |
| 5 | GND pin No. | 6 | Reference value |
| 7 | Tolerance | 8 | Range |
| 9 | Part location | 10 | Delay |
| 11 | Spare | | |

842079

*** MODIFY MENU ***

D: DISPLAY 20 LINES FROM SPECIFY STEP
I: INSERT SPECIFY STEP
K: DELETE SPECIFY STEP
C: CHANGE SPECIFY STEP
A: ERROR SET OF EACH PART
E: SAVE MODIFIED FILE or END OF INSERT
KEY-IN COMMAND & STEP No. (ex. D1 <CR>) ? I1

(If I1 is typed in:)

0001,R0001,001,002,003,499. 0,10%,3,00,0,0
0001,

KEY-IN DATA & <CR> or <CR> ONLY

To complete insert operation, type in E.

To insert a step, specify the larger step number of the two step numbers between which insertion will occur.

*** MODIFY MENU ***

D: DISPLAY 20 LINES FROM SPECIFY STEP
I: INSERT SPECIFY STEP
K: DELETE SPECIFY STEP
C: CHANGE SPECIFY STEP
A: ERROR SET OF EACH PART
E: SAVE MODIFIED FILE or END OF INSERT
KEY-IN COMMAND & STEP No. (ex. D1 <CR>) ? K1 (If K1 is typed in:)

DELETE NO. 0001 (Deleted step number.)

When insert or delete operation is completed, the steps will automatically be renumbered.

*** MODIFY MENU ***

D: DISPLAY 20 LINES FROM SPECIFY STEP
I: INSERT SPECIFY STEP
K: DELETE SPECIFY STEP
C: CHANGE SPECIFY STEP
A: ERROR SET OF EACH PART
E: SAVE MODIFIED FILE or END OF INSERT
KEY-IN COMMAND & STEP No. (ex. D1 <CR>) ? C1

(If C1 is typed in:)

0001,L0001,004,005,006,0.62mH,10%,4,00,0,0
0001,

KEY-IN DATA & <CR> or <CR> ONLY

802080

When update operation is to be executed, the contents of the pertinent step will be displayed on the screen as shown above. For the items requiring no update, press the **RETURN** key to proceed with the next item. For the items requiring update, type in the replacement data, then press the **RETURN** key.

If the entire step is to be updated, type in the full replacement data from the beginning. If you made a typing error, start it over with **CXX** again.

To delete the GND pin number information, type in an @ mark.

***** MODIFY MENU *****

D: DISPLAY 20 LINES FROM SPECIFY STEP
I: INSERT SPECIFY STEP
K: DELETE SPECIFY STEP
C: CHANGE SPECIFY STEP
A: ERROR SET OF EACH PART
E: SAVE MODIFIED FILE or END OF INSERT
KEY-IN COMMAND & STEP No. (ex. D1 <CR>) ? A (If A is typed in:)

ERROR SET
R? ? 10
C? ? 20
L? ? 30
T? ? 40
D? ? 50
J? ? 60
S? ? 70
CHANGING DATA !!

} Tolerance data for each part type can
be updated for all the steps.

842081

*** MODIFY MENU ***

D: DISPLAY 28 LINES FROM SPECIFY STEP
I: INSERT SPECIFY STEP
K: DELETE SPECIFY STEP
C: CHANGE SPECIFY STEP
A: ERROR SET OF EACH PART
E: SAVE MODIFIED FILE or END OF INSERT
KEY-IN COMMAND & STEP No. (ex. D1 <CR>) ? E (If E is typed in:)

DATA SAVED B:DSSA2.EXC !!

When the corrected file is stored, control returns to the main menu.

822082

5.11 PRINT TEST DATA PROGRAM OPERATION

The host processor UNIVAC UP10E contains a standard Centronix printer interface. The external printer to be used with the tester should have a Centronix interface. Depending on the printer used, the interface connector pin configuration may not match with that on the host processor. Check the pin assignment on the printer connector.

The listing program can print data also on the display, as well as an external printer (in an interactive manner).

Press the function key PF8;

```
PRINT TEST DATA

SELECT FILE ATTRIBUTE (1-DAT/2-DSB/3-EXC/0-END) 1

6 CHARACTERS FILE NAME --> KEY-IN

DSSA2 .DAT      A200 .DAT      DSSA22 .DAT      CK512 .DAT
JALC55 .DAT     SH01A .DAT     DEMO .DAT        ABC .DAT
TEST99 .DAT
```

FILE NAME DSSA2

The machine will first ask the file name to be printed. Since the file name differs depending on the selected menu, specify its attribute. The display will show the file names with the specified attribute. Now type in the file name. The attributes are as follows:

```
Initial data creation file name: Attribute, .DAT --- 1
Learned data file name:           Attribute, .DSB --- 2
Execution reference data file name: Attribute, .EXC --- 3
```

Zero returns to the MENU.

Now specify the output device from CRT (C) and printer (P).

Output operation can be suspended by operating the space key, and can be resumed by operating the same key a second time.

SELECT OUTPUT DEVICE (C=CRT/P=PRINTER) ? C

STEP	PARTS	+PIN	-PIN	GND.PIN
0001,	R0001	001	002	003
0002,	L0001	004	005	006
0003,	C0001	007	008	009
0004,	D0001	010	011	012
0005,	R0001	005	006	007
0006,	L0001	008	009	010
0007,	C0001	011	012	013
0008,	D0001	014	015	016
0009,	R0001	010	011	012
0010,	L0001	013	014	015
0011,	C0001	016	017	018
0012,	D0001	019	020	021
0013,	R0001	014	015	016
0014,	L0001	017	018	019
0015,	C0001	020	021	022
0016,	D0001	023	024	025

SELECT FILE ATTRIBUTE (1-DAT/2-DSB/3-EXC/0-END)

5.12 MAINTENANCE and MODIFY PROGRAM OPERATION

Press the function key PF9 .

This program is mixed MAINTENANCE and MODIFY programs, then please refer to each operation. When zero is selected, the control returns to the main menu.

```
Select: ***** MAINTENANCE ***** ----- 1
          *****  MODIFY          ***** ----- 2
          *****  MENU            ***** ----- 0
```

1, 2 or 0


842084

5.13 PRINT FORMAT

The printer prints data in the following three formats:

- (1) Failure data only.
- (2) All data print.
- (3) Statistical data print.

(1) Failure data print



*(MESURED DATA)

1. SHORT CHECK: In case of 0 to 9.99Ω (FALSE) Printed as SHORT in RED
2. JUMPER CHECK: More than 10Ω (FALSE) Printed as OPEN in RED

(2) All print

Similar to failure data print, all data other than failure data (which is print in red) is printed in black.

However,

- * 10Ω or more for short check (pass) is printed as "OPEN" in black.
- * 0 to 9.99Ω (pass) for jumper check is printed as *measured data* in black..

5802788

(3) Statistical data print

**** STATISTICS ****

TEST NUMBERS 36SHT

FAIL NUMBERS 21SHT

← Print in red.

*** FAIL DETAILS ***

STEP	FAIL NUMBERS
------	--------------

0015	1
------	---

0041	16
------	----

0043	6
------	---

0062	1
------	---

0069	4
------	---

For statistical data, the number of tested cards, that of failed cards, and step-number classified failure count are printed.

5.14 DAILY OPERATING PROCEDURES

The following describes daily operating procedures for testing the same model everyday for a certain period of time.

5.14.1 Ensure that the air pressure in the mechanism section is on, then set the main POWER switch (on the controller) to ON. Since the previous reference data remains in the controller (by battery back-up), the controller need not be placed in the online mode to the host processor.

5.14.2 When printout is desired only for failure data, no particular operation is needed because the tester's initial default is in failure print mode.

If printout of all test results is desired, press the ALL PRINT switch on the controller.

5.14.3 Place the card to be tested on the pin board. Press and hold the two TEST switches simultaneously until the press head is completely lowered.

882088

5.14.4 When the press head is completely lowered, the test sequence will be automatically initiated.

If a failure or failures are detected, the measured failed data is printed after execution of all test steps is completed. If all test items have been passed, the PASS indicator on the mechanism section will come on. The press head is automatically raised when all the test steps are completed. (A press head operation alarm will sound also when the press head is being raised after learning.)

5.14.5 Replace the card, then press the TEST switches again to repeat the same test sequence for the new card.

5.15 SWITCHING THE CARD MODEL TO BE TESTED

It is assumed that the execution reference data (program) for the new model is already completed.

5.15.1 Replacing the Pin Board

Replace the pin board with the new one which is desired for the card model to be tested.

Remove the pin board retention bolts from the bottom of the pin board jig on the mechanism section.

Pull the pin board jig fully forward, and disconnect the inter-connecting cable from the rear of the pin board jig.

After pulling out the entire pin board jig, remove the board retention screws from the jig and replace the pin board.

After replacing the pin board, push the entire jig into its original position, connect the rear cable to the jig, then reinstall and tighten the jig retention bolts.

When reconnecting the cables, be sure to cross-connect them.

5.15.2 Replacing the Execution Reference Data

After operating the host processor, powering the controller section, and placing the controller in the online mode according

842887

to the procedure given in 5.2, start up the execution reference data (program) transfer program, and type in the necessary file name from the keyboard to transfer the new file name from the host to the controller's memory. At this time, exercise care to type in the correct file name.

Now the switching of the card model is completed.

You can place the controller in the offline mode, and execute the daily test procedure (as described in 5.12) only on the tester.

5.16 WORK FILE CREATING PROCEDURES

APC-1000 AUTOMATIC
PC BOARD CHECKER
SYSTEM

Contains all the programs for the APC-1000. This diskette should normally be placed in Drive A.

APC-1000 AUTOMATIC
PC BOARD CHECKER
WORK FILE

Work file containing APC-1000 initial data, learned data, execution reference data, and other files. It is normally placed in Drive B.

UNIVAC
UP10E MODEL 10/15
SYSTEM DISK
CP/M.V. 2.2
SBASIC III V.3.0

System diskette for the host processor UNIVAC UP10E. It contains the CP/M and SBASIC.

8X2088

When creating a work file on a new diskette, the diskette must be formatted (initialized).

Formatting a diskette

Place the UP10E CP/M system diskette in Drive A.

Press the **CTRL** and **RESET** keys simultaneously; a prompter A> will appear on the screen.

After executing "A> **FORMAT** **RETURN**", insert a new diskette into drive A, then press the **Y** key. The drive will initiate formatting. When formatting is completed, a message "FORMATTING" will appear on the screen, then disk test will be executed for approximately two minutes.

When disk test is completed, a message "DISK TEST COMPLETED" will be displayed. Formatting is now completed. While another formatting can subsequently be done, press the **CTRL** and **C** keys at the same time to terminate the **FORMAT** command.

The next thing required is to load the system program (SYSGEN).

SYSGEN procedure

Place the UP10E CP/M system diskette in Drive A.

Simultaneously press the **CTRL** and **RESET** keys; a prompter A> will appear on the screen.

After executing "A> **SYSGEN** **RETURN**", type in "A" in response to the question "SOURCE DRIVE NAME?" from the machine. Press the **RETURN** key in response to "SOURCE ON A THEN TYPE RETURN", then insert the formatted diskette into Drive B.

Type in "B" in response to "DESTINATION DRIVE NAME" message, then strike the **RETURN** key in response to "DESTINATION ON X, ----" message.

When everything is completed, "FUNCTION COMPLETE" will be displayed. While another SYSGEN may subsequently be performed on another diskette, press the **CTRL** and **RESET** keys to return to the CP/M prompter A>.

Next, write PIP command into this work file.

842089

Writing PIP command

Place the UP10E CP/M system diskette in Drive A.

Simultaneously press the **CTRL** and **RESET** keys; the prompter A> will appear on the screen.

Insert the work file diskette (for which formatting and SYSGEN are completed) into Drive B.

Execute "A> PIP B: =PIP.COM **RETURN**". The PIP command is now written into the work file.

The new work file has now been completed. It is advisable that all new diskettes you have be formatted at a time.

The PIP command written in the work file is used for work file back up to be described in the following.

For more details, see the UP10E Processor Operation Manual.

Note. If a work file contains data learned from ten cards each requiring the full 1024 test steps and the execution reference data file, with unnecessary files left undeleted, it can contain data for only up to four card models. It is advisable that data for each card model be stored in individual work file.

5.17 MAKING A BACKUP DISKETTE

To protect precious information from accidental damage or destruction, it is advisable to make a back-up diskette for every diskette which contains important data.

The back-up diskette should be a new, blank diskette which is formatted according to the formatting procedure (for the back-up diskettes for work files and system diskette, execute SYSGEN, as well as formatting).

The back-up procedure differs depending on the supplied diskette types. See the following:

Making a back-up for work file diskette

Place the work file diskette in Drive A, and the back-up diskette (for which formatting and SYSGEN is completed) in Drive B.

842090

Simultaneously press the **CTRL** and **RESET** keys; the prompter A> will appear on the screen. Execute "A> PIP B: A: *.* **RETURN**". The entire work file is now copied from Drive A onto Drive B.

Making a back-up for the APC-1000 system diskette

Place the original UP10E CP/M system diskette in Drive A. Simultaneously press the **CTRL** and **RESET** keys; a prompter A> will appear on the screen. Execute "A> **DCOP** **RETURN**", then insert the APC-1000 system diskette into drive A in place of the UP10E CP/M system diskette, and a formatted back-up diskette into Drive B. Type in "S" **RETURN** in response to TYPE S or V on the screen. Duplication is completed when the message "FUNCTION COMPLETED" appears on the screen. Now all the contents of the system diskette are duplicated on the back-up diskette.

Making a back-up for the UP10E CP/M system diskette

Place the original UP10E CP/M system diskette in Drive A. Simultaneously press the **CTRL** and **RESET** keys; a prompter A> will appear on the screen. Place a new diskette (for which formatting and SYSGEN is completed) in Drive B. Execute "A> PIP B: =A: *.* **RETURN**". Now all the contents of the UP10E CP/M system diskette are duplicated on the back-up diskette in Drive B.

The APC-1000 System Diskette causes the SBASIC on the CP/M and the programs in the APC-1000 program menu both to be automatically started.


For more details of diskette copy, refer to the Operation Manual for the UP10E Processor.

842091

6. THEORY OF OPERATION

6.1 BLOCK DIAGRAM

Figure 6.1 Block diagram



The APC-1000 tester has the configuration shown in Fig. 6.1. The controller uses an integral microprocessor, control program ROM, and backed-up RAM.


The controller is attached to the host processor via parallel interface.

8422092

6.2 THEORY OF MEASUREMENT

6.2.1 Measurement of Resistance

Figure 6.2 Measurement of resistance



Vs: Reference voltage

Rs: Reference resistor

Rx: Resistance under measurement

Rx range	Vs	Rs	Range data	
0.1 ~ 9.99Ω	1V	10Ω	1	--- SHORT/JUMPER
~ 99.9Ω	"	100Ω	2	
~ 999.Ω	"	1KΩ	3	--- DIODE/TRANSISTOR
~ 9.99KΩ	"	10KΩ	4	
~ 99.9KΩ	"	100KΩ	5	
~ 999.KΩ	"	1MΩ	6	
~ 3.99MΩ	0.1V	1MΩ	7	
Open or inmeasurable			8	(Displays 999.00.)

The theory of resistance measurement and measurement ranges for automatic data learning are shown above.

When Rx is infinite, the application voltage is suppressed to approximately ±2.5 V by an over-voltage protection.


The equivalent resistance of transistors or diodes is measured with a fixed Rx range of 999Ω. Therefore, Vs is 1 V and Rs is 1 KΩ, and a constant current of 1 mA is applied for normal operation.

Short circuit and jumper conduction check is accomplished in another fixed range of 9.99Ω.

842093

6.2.2 Inductance Measurement

Figure 6.3 Inductance measuring setup



Vs: Reference AC voltage source

Rs: Reference resistance

Lx: Inductance under measurement

Lx range	Vs	Rs	Range data
10 ~ 99.9 μ H	15.92KHz	10 Ω	2
~ 999. μ H	15.92KHz	100 Ω	3
~ 9.99mH	15.92KHz	1K Ω	4
~ 99.9mH	1.592KHz	1K Ω	5
~ 399.mH	1.592KHz	10K Ω	6

The inductance measuring setup and measurement ranges for automatic data learning are shown above.

The application voltage to Lx is suppressed to approximately ± 2.5 V by an overvoltage protection.

6.2.3 Capacitance Measurement

Capacitance may be measured with two different methods. Since the optimum range is selected for data learning, the operator need not be aware of the measuring method used.

The following describes the Z method for measurement of up to 9.99 μ F, and the TC method for the measurement of more than 10 μ F.

822094

6.2.3.1 Z method




Figure 6.4 Z method for capacitance measurement

Vs: Reference AC voltage source

Rs: Reference resistance


Cx: Capacitor under measurement

Cx range	Vs	Rs	Range data
10 ~ 99.9pF	15.92KHz	100KΩ	2
~ 999.pF	15.92KHz	10KΩ	3
~ 9.99nF	15.92KHz	1KΩ	4
~ 99.9nF	1.592KHz	1KΩ	5
~ 999.nF	1.592KHz	100Ω	6
~ 9.99μF	1.592KHz	10Ω	7

The application voltage to Cx is suppressed to approximately ±2.5 V by an overvoltage protection.

6.2.3.2 TC method

Figure 6.5 TC method for capacitance measurement



242095

Vs: Reference voltage
 Rs: Reference resistance
 Cx: Capacitor under measurement

Cx range	Vs	Rs	Range data	Clock
~ 99.9 μ F	1V	1K Ω	5	10KHz
~ 999. μ F	1V	100 Ω	6	10KHz
~ 3.99mF	1V	100 Ω	7	1KHz
Short or open			8	

(999.0F display)

The application voltage to Cx is suppressed to approximately ± 2.5 V by an overvoltage protection.

6.3 THREE-TERMINAL GUARD METHOD

If the two-terminal method is used for in-circuit measurement of part constants, high measurement accuracy will not be guaranteed due to round-about impedance.

To assure high accuracy in-circuit measurement, the APC-1000 allows the operator to program the three-terminal guard method.

Figure 6.6 shows the theory of the three-terminal guard method:




Figure 6.6 Three-terminal guard method

In Figure 6.6, the serial resistors of RA and RB are connected in parallel with the resistor (Rx) to be measured.

Since good measurement accuracy is not obtained only with the measurement across Rx (+ and -), the node \textcircled{G} of RA and RB is

842091

specified as ground, so that the node \textcircled{G} is at the same level as the imaginary ground of the amplifier.

As a result, no current flows through R_A , and only the current passing through R_X can be measurement. This means that the measurement of R_X is not affected by the impedance of R_A and R_B .

On the APC-1000, any pin or node can be specified as ground.

This three-terminal guard method is effective also for in-circuit measurement of capacitors, inductors or resistors.

6.4 MEASUREMENT DELAY

When measuring a resistance in a circuit network wherein the resistor under measurement is connected in parallel with a capacitor, it is preferable that measurement be started after the parallel capacitor is fully charged up.

To enable this, a measurement delay can be specified for resistance measurement, as shown below:




Figure 6.7 R/C parallel network

Measurement delay	0: 0 ms	6: 300 ms	C: 600 ms
	1: 50 ms	7: 350 ms	D: 650 ms
	2: 100 ms	8: 400 ms	E: 700 ms
	3: 150 ms	9: 450 ms	F: 750 ms
	4: 200 ms	A: 500 ms	
	5: 250 ms	B: 550 ms	

For the parallel circuit as shown in Figure 6.8, measurement delay need not be specified if the node \textcircled{G} is specified as the ground for the three-terminal guard method.




Figure 6.8 R/C serial-parallel network

8420997

6.5 JUDGEMENT CRITERION ERROR

When execution reference data is created after learned data is averaged, the error range of the judgement criterion is $\pm 10\%$ of the default value.

This error range may be altered by using the correction program. Alteration may be done for each test step or for each part type.

However, for short circuit or jumper conduction check, the range of 0 to 9.99Ω is used, with the measured range of 0 to 9.99Ω identified as a failure for short circuit, and that of above 10Ω identified as good. For jumpers, the measured range of 0 to 9.99Ω is identified as good, while that of less than 10Ω is identified as failure.

This means that the error range specification (e.g. $\pm 10\%$) for short circuit or jumper does not affect the judgement criteria.

8/22/98

7. PIN BOARD DESIGN

7.1 CIRCUIT EXAMPLE AND PIN ASSIGNMENTS

Figure 7.1 shows a circuit example in which node numbers 0 through 8 are specified for programming the initial data creation program. Data learning is executed by using this program.




Figure 7.1 Circuit example

Step No.	PARTS	+PIN	-PIN	GND·PIN	Remarks
1	C1	1	3		
2	R1	2	3		
3	R2	0	3		
4	R3	5	2		
5	R4	4	0		Measurement delay
6	R5	0	6		
7	R6	2	7		DC resistance of relay
8	C2	4	0		Error present due to R4.
9	T1	3	4	0	
10	T2	6	8	3	(GND node) 3, 2, or 5
11	D1	6	5	2	(GND node) 2, 3, or 0
12	D2	7	2		Paralleled with R6.
13	J1	8	0		Jumper check
14	S1	2	0	3	Short circuit check
15					
16					

862098

7.2 PIN ASSIGNMENTS

The following shows the pin jig connector pin assignments for connector wiring:

Connector type : Amphenor 50-pin connector 57-40500
 Number of connectors: 6 for standard 256 pins.
 12 for expanded 512 pins (6 additional connectors used.)





Figure 7.2 Connector numbers (viewed from front)

As shown in Figure 7.3, pin number specifications on the program are determined according to the pin numbers on each connector.

For the standard 256 pins, 0 through 255 is specified on the program. For the expanded 512 pins, 0 through 511 are programmed.

Pins 25 and 50 of each connector are assigned to guard pins. However, pins 25 and 50 of connector No.1 should be connected to the metal part (any location) on the connector bracket.



APC-1000 [PIN ASSIGNMENT]

Pin No.	No.1 PROG No.	No.2 PROG No.	No.3 PROG No.	No.4 PROG No.	No.5 PROG No.	No.6 PROG No.	No.7 PROG No.	No.8 PROG No.	No.9 PROG No.	No.10 PROG No.	No.11 PROG No.	No.12 PROG No.
1	0	48	96	144	192	240	256	304	352	400	448	496
2	1	49	97	145	193	241	257	305	353	401	449	497
3	2	50	98	146	194	242	258	306	354	402	450	498
4	3	51	99	147	195	243	259	307	355	403	451	499
5	4	52	100	148	196	244	260	308	356	404	452	500
6	5	53	101	149	197	245	261	309	357	405	453	501
7	6	54	102	150	198	246	262	310	358	406	454	502
8	7	55	103	151	199	247	263	311	359	407	455	503
9	8	56	104	152	200	248	264	312	360	408	456	504
10	9	57	105	153	201	249	265	313	361	409	457	505
11	10	58	106	154	202	250	266	314	362	410	458	506
12	11	59	107	155	203	251	267	315	363	411	459	507
13	12	60	108	156	204	252	268	316	364	412	460	508
14	13	61	109	157	205	253	269	317	365	413	461	509
15	14	62	110	158	206	254	270	318	366	414	462	510
16	15	63	111	159	207	255	271	319	367	415	463	511
17	16	64	112	160	208		272	320	368	416	464	
18	17	65	113	161	209		273	321	369	417	465	
19	18	66	114	162	210		274	322	370	418	466	
20	19	67	115	163	211		275	323	371	419	467	
21	20	68	116	164	212		276	324	372	420	468	
22	21	69	117	165	213		277	325	373	421	469	
23	22	70	118	166	214		278	326	374	422	470	
24	23	71	119	167	215		279	327	375	423	471	
25	GUARD					GUARD						
26	24	72	120	168	216		280	328	376	424	472	GUARD
27	25	73	121	169	217		281	329	377	425	473	
28	26	74	122	170	218		282	330	378	426	474	
29	27	75	123	171	219		283	331	379	427	475	
30	28	76	124	172	220		284	332	380	428	476	
31	29	77	125	173	221		285	333	381	429	477	
32	30	78	126	174	222		286	334	382	430	478	
33	31	79	127	175	223		287	335	383	431	479	
34	32	80	128	176	224		288	336	384	432	480	
35	33	81	129	177	225		289	337	385	433	481	
36	34	82	130	178	226		290	338	386	434	482	
37	35	83	131	179	227		291	339	387	435	483	
38	36	84	132	180	228		292	340	388	436	484	
39	37	85	133	181	229		293	341	389	437	485	
40	38	86	134	182	230		294	342	390	438	486	
41	39	87	135	183	231		295	343	391	439	487	
42	40	88	136	184	232		296	344	392	440	488	
43	41	89	137	185	233		297	345	393	441	489	
44	42	90	138	186	234		298	346	394	442	490	
45	43	91	139	187	235		299	347	395	443	491	
46	44	92	140	188	236		300	348	396	444	492	
47	45	93	141	189	237		301	349	397	445	493	
48	46	94	142	190	238		302	350	398	446	494	
49	47	95	143	191	239		303	351	399	447	495	
50	GUARD					GUARD						GUARD

Figure 7.3 Pin assignment

10/27/88

7.3 PIN JIG PARTS AND ASSEMBLY DRAWINGS

For the preparation of the pin jig for each card model, install contact pins on the PCB PIN BOARD (acrylic 5 mm thick) shown in a separate drawing, mount the necessary 50-pin connector on the connector bracket and make the pertinent wiring to it, then store the front bracket while it is installed on the acrylic pin board.

These correspond to (1), (3), and (6) of the pin board ass'y drawings. However, when contact pins are installed on the pin board, mount the spacers (5) in the appropriate locations, so as to prevent the board from warping due to the pressure of the press head.

When replacing the completed pin jig with another completed jig, remove the flat head screws from the Base Plate (4) and the screws from the Side Plates (8) and (9).


When creating a new pin jig, refer to each drawing.

If a pin board thickness of other than 5 mm (e.g. 10 mm) is desired, the PCB PIN BOARD (1), BRACKET (3), CONNECTOR BRACKET (6), SIDE PLATES (8) and (9), and SPACER (5) shown in the Pin Board Ass'y drawing require replacement.

For the appropriate press head stroke, adjust the push rod by referring to Figure 7.4 Press stroke.

842102

842103




Polyacrylate (clear) t5

PCB PIN BOARD

APC-1000

317022

842104




Cold Rolled Carbon Steel Sheet t2
 Electroplated Coating of Nickel

BRACKET FOR CONNECTOR

APC-1000

317037

842105




Cold Rolled Carbon Steel Sheet t2
Electroplated Coating of Nickel

BRACKET

APC-1000

317034




Bakelite Laminated Rod 10DIA

SPACER

APC-1000

419251


SK2106



PCB PUSH BOARD

APC-1000 317021

802288




Bakelite Laminated Sheet t20 (brown)

PLATE SIDE (L)

APC-1000

317236

6012788




Bakelite Laminated Sheet t20 (brown)

PLATE SIDE (R)

APC-1000

317235


842110



Cold Rolled Carbon Steel Sheet t1.2

COVER FRONT

APG-1000 317234





Bakelite Laminated Sheet t5 (brown)

BASE PLATE

APC-1000 24662

842111

211278



PIN BOARD ASSEMBLY
APC-1000 24663




Figure 7.7 Press stroke

842113 A
 17 9 78

8. NOTES AND PRECAUTIONS

8.1 PRECAUTIONS FOR MEASUREMENT

8.1.1 Comparison with Other Tester Models

When the APC-1000 is compared with other tester model, they may produce different measurement results from the same test object, especially for inductance measurement, due to the difference in testing frequencies, measuring levels, or the presence of DC application.

8.1.2 Measurement in Composite Circuits

While measurement accuracy can be considerably increased by the three-terminal guard method, some measurement error may be observed for resistors connected in parallel with inductors, capacitors connected in parallel with resistors, or the same parts connected in parallel.

In this case, however, parts with intolerable error can be identified since test is basically performed by comparing part constant with learned reference data.

When measuring resistance connected in parallel with capacitance, use measurement delay. The value of measurement delay should be determined by referring to the time constant obtained from the product of the resistance and capacitance.

8.1.3 Measurement Range

While reference data is automatically learned in the optimum range, it is also possible for the machine to learn data using one higher range for measured values which are more than 90% of each range (by considering the error of $\pm 10\%$ of the default value).

However, if any inadequate condition is expected from the relationship between altered judgement criterion and reference data, change the measurement range using the correction program while referring to the range listing in section 6.2.

8.1.4 Preventing Parts Under Test from Damage or Deterioration

The testing voltage applied to the parts under test is typically 1 VDC or 1 VAC rms and is suppressed to approximately ± 2.5 V under any faulty condition.

To prevent possible damage or deterioration, exercise care for test node specification and polarity by considering round-about impedances in composite networks. The above typical application voltage may, however, be applied to almost any part without the danger of damage or deterioration.

8.2 OPERATING PRECAUTIONS

8.2.1 Floppy Disk

When handling floppy disks, never fold it nor touch any of the exposed surfaces. Keep them out of direct sunlight and away from strong magnetic field.

Do not place a diskette in the drive while you are turning the host processor on or off. In other words, remove the diskette from both drives before turning the host on or off.

Do not open the door of the drive while the drive is operating.

If a diskette is inserted into or removed from the drive while the program is running, the message "Bdos Err on B: R/O" may appear on the monitor. If this occurred, simultaneously press the **CTRL** and **RESET** keys to return control to the main menu.

Each work file diskette can hold data of only up to four card models if reference data has been learned from ten cards each requiring 1024 steps, the execution reference data is stored in the work file, and none of unnecessary files is left undeleted from the work file.

It is advisable that each work file be reserved for individual card model.

842115

8.2.2 Microprocessor in the Controller Section

If the controller malfunctions, press the **CPU RESET** switch on the controller. Once the CPURESET is pressed, start the entire test sequence from the beginning again.

8.2.3 Print Paper

If paper jam or entangled ribbon is left unserviced in the printer, it may cause printer trouble.

8.2.4 Program Execution Abort and Restart

If an error occurred during program execution and the program execution was broken, it may be restarted by typing in "RUN" just following the prompter ">", then strike the **RETURN** key. The aborted program will be executed again.

>RUN **RETURN**

If you press the **CTRL** and **RESET** keys, control will return to the main menu.

To abort the current program execution, simultaneously press the **CTRL** and **C** keys. It may be restarted by following the procedure described just above.

8.3 MECHANISM SECTION AND MULTIPLEXER

8.3.1 Press Head Stroke

Adjust the press head stroke by means of the push rod according to each card type to be tested. If needed, install washers on the push rod for stroke adjustment.

Stroke adjustment will be require after contact pins are altered (see Figure 7.4 Press head stroke.).

8.3.2 Air Control Valve

Drain water from the glass section of the air control valve before accumulation of water becomes excessive.

8.3.3 CUD Discharging

If a card with electrostatic charge accumulation is tested on the tester, the relay contacts in the multiplexer unit may fuse. Cards just after subjected to electrical check often has static accumulation. Discharge such cards before placing it on the tester.

8.3.4 Contamination of Contact Pins

Do not leave any contact pins left contaminated. Flux may often be a cause of defective pin contact. Clean the contact pins with a brush some twice per day.

8.3.5 Emergency Press Head UP Switch

After test execution is completed, the press head is automatically

APC-1000

ALL PINS SHORT CHECK

OPERATION MANUAL

KIKUSUI ELECTRONICS CORPORATION

84.6.21

S-842914

This operation manual describes details of all pins short check function and its operation method in a program.

1. Explanation of details of all pins short check

A. Procedures for data learning

- 1) Input information "150" with a key, when pins used as instruments are, for instance, 0 - 150.
- 2) Conduct tests at "0" to "150" one after the other, and memorize the positions of the short.

0 ↔ 1 to 150 shortcircuited

1 ↔ 0 and 2 to 150 shortcircuited

⋮

- 3) Make an entire test of positions of the shorts and memorize them. This will be learned data. Data composition is as follows.

0	1, 3
1	0, 3
3	0, 1
15	17, 140
⋮	⋮
↑	↑
Pins tested	Pins not tested

Conduct tests on all the pins except the above pins.

B. Containment of executed program

- 1) Data obtained in A.3) is transmitted.

C. Execution

- 1) Conduct short check for all pins according to data contained at B.10, before the execution of measurement. If there is an error, it should be printed out.

- 2) If there are errors in all pins short check, do not move on to the measurement of resistances, condensers, etc., but stop.

2. Procedures of all pins short check

When conducting all pins short check, it is necessary to make a file for checking all pins except those pins such as jumperpins which have shorts on normal base plates from the start.

To make this file, there are two ways: by learning of shorted pins and by inputting those pins by the operator manually.

For the operator to input data manually, the **PF1** function key of the initial data making mode is pressed and the following indication will appear.

```
***** INPUT INITIAL DATA *****  
  
FUNCTION 1 ..... INPUT INITIAL DATA OF ALL PINS SHORT CHECK  
FUNCTION 2 ..... INPUT INITIAL DATA OF COMPONENTS TEST  
FUNCTION 3 ..... RETURN TO MENU DISPLAY  
  
THEN PRESS FUNCTION KEY
```

When making a file of all pins check, press the **PF1** function key. The following indication will appear and explain the input method.


```

***** INPUT INITIAL DATA OF ALL PINS SHORT CHECK *****
MAX PIN ..... 999
                1
REF PIN   PASS PIN
999 ..... 999, 999, 999, 999, 999, 999, 999, 999, 999, 999(CR)
  2                3                4

1: MAXIMUM PIN NUMBER
2: REFERENCE PIN NUMBER
      E: END OF INPUT      #: INPUT MODIFY
3: PASS PIN NUMBER
      KEY-IN SHORTED PIN NUMBERS AGAINST THE REFERENCE PIN
      AND USE COMMA (,) AS A DELIMITTOR
4: PRESS [RETURN] KEY AS END OF PASS PIN NUMBER

      THEN PRESS [RETURN] KEY TO INPUT THESE DATAS !!

```

After reading the explanation, press the RETURN key.
 Next let's explain how to register file names.

```

***** INPUT INITIAL DATA OF ALL PINS SHORT CHECK *****
      KEY-IN FILE NAME ( MAX 6 CHARACTERS )
KMT04 .PAS      A      .PAS      LN00 .PAS      B      .PAS
XYZ   .PAS
      FILE NAME

```

Input the file name within 6 characters. If the file is present already, the following display will appear.
 A category of file names is .PAS.

842917

```

***** INPUT INITIAL DATA OF ALL PINS SHORT CHECK *****
                KEY-IN FILE NAME ( MAX 6 CHARACTERS )
KMT84 .PAS      A      .PAS      LN33 .PAS      B      .PAS
XYZ   .PAS
FILE NAME A
GENERATE from FIRST STEP ? (Y/N)

```

To continue to input the file already registered, press the **N** key, and to delete the registered file and make a new file, press the **Y** key.

In case of continuation, the max pin number of the file is indicated as follows.

```

***** INPUT INITIAL DATA OF ALL PINS SHORT CHECK *****
MAX PIN .....      ( MAX PIN OF FILE [ A ] IS 134 )

```

In the case where a new file is made or an existing file is remade, the following indication will appear.

```

***** INPUT INITIAL DATA OF ALL PINS SHORT CHECK *****
MAX PIN .....

```

For the MAX PIN, input the maximum pin number used.

For the REF PIN, input a representative pin number (any number) to be checked.

For the PASS PIN, input the number of shortcircuited pins except REF PINS.

For separation, use the "," key always and press the **RETURN** key at the end of the line.

Pass pins can be input in one line by 10. To input more than 10 pins, press the **RETURN** key and input REF PINS.

An example of input is shown as follows.

***** INPUT INITIAL DATA OF ALL PINS SHORT CHECK *****

MAX PIN 134

REF PIN	PASS PIN
000	014, 031, 040, 073, 097
014	000, 031, 040, 073, 097
016	130, 131

After all inputs are finished, press the **[E]** key, and the display returns to the menu for making the initial data on page-2. To return further to the main menu, press the **[PF3]**.

When making corrections, the cursor can be returned with the **[BS]** key within the line. When the error is detected after finishing a line, press the **[#]** key to go to the correction mode. (The **[#]** key should be pressed when the cursor is at the REF PIN.)

***** MODIFY INITIAL DATA *****

D: DISPLAY 20 LINES FROM RANDOM STEP
K: DELETE RANDOM STEPS
E: END OF MODIFY
KEY-IN COMMAND & STEP NO. (ex. D1 [RETURN])

Find a wrong step with the **[D]** key and delete it with the **[K]** key.

An example of D-operation .

***** MODIFY INITIAL DATA *****

D: DISPLAY 20 LINES FROM RANDOM STEP
K: DELETE RANDOM STEPS
E: END OF MODIFY
KEY-IN COMMAND & STEP NO. (ex. D1 [RETURN]) D1

STEP	REF PIN	PASS PIN
0001	000	014, 031, 040, 073, 097
0002	014	000, 031, 040, 073, 097
0003	016	130, 131

842919

An example of K-operation

```
***** MODIFY INITIAL DATA *****  
  
D:  DISPLAY 20 LINES FROM RANDOM STEP  
K:  DELETE RANDOM STEPS  
E:  END OF MODIFY  
KEY-IN COMMAND & STEP NO.( ex. D1 [RETURN] ) K  
  
KEY-IN START STEP NUMBER FOR DELETE ? 10  
KEY-IN END STEP NUMBER FOR DELETE ? 11  
  
DELETING !!
```

This operation allows deletion from Step 10 to 11.

Now let's explain how to input data by learning the shortcircuited pins. Press the **PF2** function key for learning the main menu and the following display will appear.

```
***** LEARN DATA MENU *****  
  
FUNCTION 1 ..... LEARN ALL PINS SHORT CHECK DATA  
FUNCTION 2 ..... LEARN COMPONENTS TEST DATA  
FUNCTION 3 ..... RETURN TO MENU DISPLAY  
  
THEN PRESS FUNCTION KEY
```

To learn data about all pins check, press the **PFL** function key.

```
***** LEARN ALL PINS SHORT CHECK DATA *****  
  
KEY-IN FILE NAME ( 6 CHARACTERS )  
  
KMT84 .PAS      A      .PAS      LN33  .PAS      B      .PAS  
XYZ   .PAS  
  
FILE NAME
```

842920

Input a file name within 6 characters. If the file is already present, the following display will appear.

```
***** LEARN ALL PINS SHORT CHECK DATA *****
                KEY-IN FILE NAME < 6 CHARACTERS >
KMT04 .PAS      A      .PAS      LN00 .PAS      B      .PAS
XVZ   .PAS
FILE NAME A
                THE FILE EXISTS ALREADY !!
                TRY TO LEARN-THE DATA AFRESH ? <Y/N>
```

In the case where the file already exists and was learned earlier or the file made at the time of making the initial data is to be deleted to make a new file, press the Y key, or change file names by pressing the N key.

When the N key is pressed, a file name will be asked.

When the file name is registered, the following display will appear.

In case the existed file names are learned again, a previous MAX PIN number will be displayed.

```
***** LEARN ALL PINS SHORT CHECK DATA *****
KEY-IN MAX PIN NUMBER
MAX PIN ----- < MAX PIN OF FILE [ LN00 ] IS 107 >
```

For the MAX PIN, input the maximum pin number being used. The data will be learned automatically.

An example of automatic learning

```
***** LEARN ALL PINS SHORT CHECK DATA *****  
KEY-IN MAX PIN NUMBER  
MAX PIN ..... 107      ( MAX PIN OF FILE [ LN39 ] IS 107 )  
  
REF PIN    PASS PIN  
000 ..... 014, 031, 048, 073, 097, 099, 104  
014 ..... 000, 031, 048, 073, 097, 099, 104  
016 ..... 106, 107  
010 ..... 000, 099  
020 ..... 050, 099
```

After the automatic learning finishes, the menu of data learning on page-6 will appear. To return further to the main menu, press the .

What has been described is the procedure for making a pass pin data file of all pins short check.

Now let's explain how to transmit data to the controller side. When the function key is pressed in data transmission mode of the main menu, the following display will appear.

```
***** TRANSFER EXC (EXECUTION) FILE *****  
FUNCTION 1 ..... ALL PINS SHORT CHECK DATA FILE  
FUNCTION 2 ..... COMPONENTS TEST DATA FILE  
FUNCTION 3 ..... RETURN TO MENU DISPLAY  
  
THEN PRESS FUNCTION KEY
```

Press the function key for all pins check data transmitting mode.

```

***** TRANSFER ALL PING SHORT CHECK DATA FILE *****

KEY-IN FILE NAME ( MAX 6 CHARACTERS )

LN33 .PEX      KMT04 .PEX      A      .PEX      B      .PEX
PTEST .PEX     XYZ     .PEX

FILE NAME

```

When the file name is input, data will be transmitted.

For execution, make the mode OFFLINE, and push TEST START button. All pins short check will start and so will the measurement test. In the case where the all pins short check is NG, the measurement test won't be done.

If conducting a measurement test with no short check, make the all pins check data file at the time of making the initial data, with its contents as "0" for MAX PIN; "0" for REF PIN; and "0" for the PASS PIN.

After that, the contents of the file will be transmitted.

842923




Figure 3.2 Rear cable connections

SK 2056

APC-1000

SYSTEM DISK Ver 1.8A

VERSION UP

OPERATION MANUAL

KIKUSUI ELECTRONICS CORPORATION

84.6.21

S-842924

1. Outline

System software (program) of APC-1000 has been changed from Ver 1.8 to Ver 1.8A. The changed contents and operation method are described here. This change is designed for time-saving, especially in debugging.

2. Change contents

2.1 File name is registered in the function key PF15 after it is input with any menu and executed. When the same file is wanted after the menu has been shifted, just press the function key PF15. The file name is displayed in the bottom-right of the CRT screen.

2.2 The kinds of characters used for file name have increased.

Conventionally, the first character among 6 appointed characters is an English capital, the second and following characters are English capitals and numbers. This change makes it possible to use characters for file names which can also be used in NAME commands of the BASIC mode and REN commands of the CP/M mode of the computer.


That is; the first character among 6 characters appointed is an English capital, A to Z, or the symbol-\$; the second and following characters are English capitals, A to Z, numbers, 0 to 9, or symbols such as #, %, &, (,), +, \$, -, /.

2.3 Maintenance & correction program

Correction or execution with the C command has become possible right after the execution of (T command, N command, R command) any step.

In particular, previously executed step numbers are stored and can be recalled just by pressing each command (T, N, R, C, D) and RETURN at the time of the next execution or correction. This makes it much easier to execute or correct the same step number. Details are explained in the chapter on Operation Method.

2.4 When correcting the contents of any step number with C command, the part numbers and values of + pin, - pin and GND pin can be changed only by inputting the effective number (eg. only "5" in case of "005") just as writing initial data. When inputting value data, and especially item units of standard data, the units which have been registered in the function key appear at the bottom of the CRT screen and the relevent keys should then be pressed.



Once values and units of standard data have been input, the range information item is automatically displayed, eliminating the need for manual input.

For the item of PARTS LOCATION, English capitals (A to Z), lower cases (a to z) and numbers (0 to 9) can be used for both 2 digits.

For the item of error setting, the symbol % is automatically displayed after inputting 2-digit numbers. (Note: Input should be "05", incase of 5%.)

Where part types are short (S) or jumper (J), items of standard data, error and range are automatically displayed.

During the correction of one step, the cursor is returned to the preceding letter which is deleted, by pressing the BS key at the same time. This makes it easier to correct a wrong key input.

In the case of no change, or after a change, programs can be continued by pressing the RETURN key.

2.5 The program has been revised to execute the "maintenance and correction" function (9), when function (6) maintenance or function (7) is selected.

2.6 Menus are indicated as follows.

```
.APC-1000  AUTOMATIC PC BOARD CHECKER (Ver 1.8A)
*****      MENU      *****
*
*  FUNCTION 1 ----- INPUT INITIAL DATA  *
*  FUNCTION 2 ----- LEARN DATA          *
*  FUNCTION 3 ----- AVERAGE OF LEARNED DATA *
*  FUNCTION 4 ----- TRANSFER OF EXC FILE  *
*  FUNCTION 5 ----- STATISTICS           *
*  FUNCTION 6 ----- MAINTENANCE          *
*  FUNCTION 7 ----- MODIFY               *
*  FUNCTION 8 ----- PRINT TEST DATA     *
*  FUNCTION 9 ----- MAINTENANCE & MODIFY *
*
*****
                                THEN PRESS FUNCTION KEY
```

842927

3. Operation method

A detailed operation method of "maintenance & correction" program is described.

Firstly, when executing this menu, the following indications appear in the input mode of the file name:

```
***** MAINTENANCE & MODIFY *****
KEY-IN FILE NAME ( MAX 6 CHARACTERS )

LN33 .EXC      AL(2) .EXC      XYZ .EXC      QNKS .EXC
$TEST .EXC     TEST/1 .EXC     TY5D .EXC    ABCD# .EXC
KMT04 .EXC

FILE NAME

PF15
ABCD#
```

A list of the execution files (xxx.EXC) contained in the WORK FILE of B drive is displayed, and file names which have previously been operated and registered in the function key.

are displayed at the bottom right.

To retrieve the same file name, just press .

3.1 Command display

When a file name is input the following; Maintenance commands (T, N, R), Correction commands (C, I, K, A), Display command (D) and End command (E) appear, then units at the time of data correction appear at the bottom of the screen just as they are stored in the function keys.

```
***** MAINTENANCE & MODIFY *****

D:  DISPLAY 15 LINES FROM RANDOM STEP
T:  TEST OF RANDOM STEP
N:  NEXT STEP TEST
R:  REPEAT TEST OF SAME STEP
I:  INSERT RANDOM STEPS
K:  DELETE RANDOM STEPS
C:  CHANGE OF RANDOM STEP
A:  ERROR SET OF EACH PART
E:  END < MODIFY, INSERT, TEST >

KEY-IN COMMAND & STEP No. < ex. D1 [RETURN] >

PF4  PF5  PF6  PF7  PF8  PF9  PF10  PF15
SPACE k  M  P  n  u  m  ABCD#
```

842929

3.2 Operation of D command

15 steps from any step are indicated. For D command, there are 3 types of operation methods.

3.2.1 Dxxx RETURN (xxx: step No.)

When D-command and any step No. are input, 15 steps from xxx step are indicated.

3.2.2 DN

15 steps from the currently displayed step number of +15, (display, execution, correction etc.) are displayed. (That is, the next 15 steps).

3.2.3 D RETURN

15 steps from the step number being executed, changed or indicated are displayed.

At the time of initial operation, display starts from step "1".

```
***** MAINTENANCE & MODIFY *****  
  
D:  DISPLAY 15 LINES FROM RANDOM STEP  
T:  TEST OF RANDOM STEP  
N:  NEXT STEP TEST  
R:  REPEAT TEST OF SAME STEP  
I:  INSERT RANDOM STEPS  
K:  DELETE RANDOM STEPS  
C:  CHANGE OF RANDOM STEP  
A:  ERROR SET OF EACH PART  
E:  END ( MODIFY, INSERT, TEST )  
  
KEY-IN COMMAND & STEP No. ( ex. D1 [RETURN] ) D.  
  
0001,R0001,002,000, ,123. o,15%,3,A5,1,0  
0002,C0001,005,006,007,125.pF,20%,3,B3,0,0  
0003,T0005,045,026,000,650. o,10%,3,C2,2,0  
0004,D0003,023,024,044,665. o,15%,3,F3,3,0  
0005,J0001,001,010, ,9.99 o,10%,1,D4,0,0  
0006,S0002,005,009, ,9.99 o,10%,1,A2,0,0  
0007,L0005,011,022, ,2.50mH,25%,4,E0,0,0  
0008,R0002,010,020,030,26.7ko,15%,5,B7,5,0  
0009,R0003,055,066,077,46.0ko,15%,5,A9,3,0  
0010,J0055,123,045, ,9.99 o,10%,8,F1,0,0  
0011,R0004,051,062, ,211.ko,15%,6,B5,6,0  
0012,C0006,024,051,055,5.62nF,20%,4,A1,1,0  
0013,C0012,033,045,060,2.93mF,0x3,7,F0,0,0  
0014,C0020,004,003,000,659.pF,20%,3,B6,1,0  
0015,R0015,020,011,035,0.92ko,15%,4,C4,2,0  
  
PF4 PF5 PF6 PF7 PF8 PF9 PF10 PF15  
SPACE k M P n u m ABCD#
```

842930

The next example is one for DN command and the operation is continued from the previous page.

As shown below, indication starts from the step number which is +15 steps to the previous start step number.

***** MAINTENANCE & MODIFY *****

D: DISPLAY 15 LINES FROM RANDOM STEP
T: TEST OF RANDOM STEP
N: NEXT STEP TEST
R: REPEAT TEST OF SAME STEP
I: INSERT RANDOM STEPS
K: DELETE RANDOM STEPS
C: CHANGE OF RANDOM STEP
A: ERROR SET OF EACH PART
E: END (MODIFY, INSERT, TEST)

KEY-IN COMMAND & STEP No. (ex. D1 [RETURN]) DN

0016,T0002,031,020, ,710. o,10%,3,B3,1,0
0017,D0009,044,051,001,685. o,15%,3,F9,3,0
0010,R0023,016,040,032,35.7 o,20%,2,A2,F,0

PF4 PF5 PF6 PF7 PF8 PF9 PF10
SPACE k M p n u m

PF15
ABCD#

3.3 Operation of C command

This is a change and correction command for any step and like D command, there are 3 types of operation methods.

3.3.1 Cxxx RETURN (xxx: Step No.)

When the C command and step number are input, the step number can be changed.

3.3.2 CN

Alterations can be made to the step following the step being displayed (or executed, corrected, etc.). This is particularly useful in cases in which changes are to be continued into the next step.

3.3.3 C RETURN

Making a change to a step number that has been executed or corrected can only be done without inputting the step number and by using C RETURN.

***** MAINTENANCE & MODIFY *****

D: DISPLAY 15 LINES FROM RANDOM STEP
T: TEST OF RANDOM STEP
N: NEXT STEP TEST
R: REPEAT TEST OF SAME STEP
I: INSERT RANDOM STEPS
K: DELETE RANDOM STEPS
C: CHANGE OF RANDOM STEP
A: ERROR SET OF EACH PART
E: END (MODIFY, INSERT, TEST)

KEY-IN COMMAND & STEP No. (ex. D1 [RETURN]) C

0016,T0002,031,029, ,710. 0,10%,3,B3,1,0
0016,

PF4	PF5	PF6	PF7	PF8	PF9	PF10	PF15
SPACE	k	M	p	n	u	m	ABCD#

The above figure is an example of what happens when the C
RETURN (from previous page) is pressed.

The following is an example of the next operation to the previous page, and is also an example of the CN command.

***** MAINTENANCE & MODIFY *****

D: DISPLAY 15 LINES FROM RANDOM STEP
T: TEST OF RANDOM STEP
N: NEXT STEP TEST
R: REPEAT TEST OF SAME STEP
I: INSERT RANDOM STEPS
K: DELETE RANDOM STEPS
C: CHANGE OF RANDOM STEP
A: ERROR SET OF EACH PART
E: END (MODIFY, INSERT, TEST)


KEY-IN COMMAND & STEP No. (ex. D1 [RETURN]) CN

0017,D0009,044,051,001,605. o,15x,3,F9,3,0
0017,

PF4 PF5 PF6 PF7 PF8 PF9 PF10
SPACE k M P n u m

PF15
ABCD#

Now let's explain the operation method in more detail. The outline has been already described in section 2.4, change contents, and the operation is as follows.



Position of inputting "E" at the time of stop

- (1) The key should be used to move ahead, after a data change or at an item requiring no change.
To move the cursor to the preceding letter, should be used. As the cursor moves deletion is achieved.
- (2) When required to stop corrections in above situation, "E" should be input when the cursor is at the first letter of a part No. (In the above case, the input position is "L")
- (3) There is no need to input "0" preceding the effective numbers of the part number +Pin, -Pin and GND Pin. In the case in the figure above; L5 → 11 → 22 → ... is enough.
- (4) When it is desired to delete the GND Pin, the space key should be struck once and should be executed when the cursor is at any position among 3 letters of the GND pin.
- (5) After the input of the value data of standard data, units can be easily be input by using the function key, where as explained in section 2.4, the beginning letter of units are registered.

The "SPACE" is same as the space key (blank key) of the

842935

key board. When the beginning letters of units are input, unit letters of O(Ω), F,H are automatically generated according to part types.

- (6) In the item of error setting, a 2-digit number ("05" in case of "5") is input, and then the symbol % is automatically displayed.
- (7) The available characters for the item of PARTS LOCATION are; English capitals (A to Z), English lower case (a to z) and numbers (0 to 9). These can be used for both of 2 digits.
- (8) Range information is automatically generated from the standard data.
- (9) DELAY (delay measurement) can be set with numbers 0 to 9 and letters A to F, and can be changed at the interval of 50 mS.
- (10) SPARE is not usable at present. Only hardware which permits external contact output at any step has been prepared in this equipment. Preparation for operation in software, however, hasn't yet been made.
- (11) When changing the steps of test items such as short (S) and jumper (J), standard data, error value and range information are automatically generated after passing the item GND Pin.
- (12) When range information is changed into "8", regardless of part and standard data, the step will be unexecuted even after transmitting the execution data.
To leave data and change only the range information to "8" (to make the step an unexecuted one), firstly position the cursor at the first letter of the standard data and then input the ESC key for all parts except short (S) and jumper (J). The information then turns to "8".
To return to the normal range after setting the range information to "8", delete the range information with BS and press

`RETURN` again and the normal range will be restored.
For short (S) and jumper (J), input the `ESC` key when the cursor is at one of the 3 letters of GND PIN or at "," after GND PIN, and the range information will change to "8". To restore the normal range, return the cursor to position of "," with `BS` and press `RETURN`, then the normal range will be returned.

3.4 Operation of T command

This is an execution (test) command at any step, and there are two types of operation methods.

3.4.1 Txxx RETURN (xxx: step No.)

Input T command and step number, the step will be executed and the measured values will be displayed.

3.4.2 T RETURN

This operation is required to execute the same step number again. (ie. to change the display etc.) (for display; the first step number)

This operation is useful to execute and correct the same step number. For example, to repeat execution and correct with T command after corrections with C command.

To execute the step number next to current step number, use N command.

***** MAINTENANCE & MODIFY *****

D: DISPLAY 15 LINES FROM RANDOM STEP
T: TEST OF RANDOM STEP
N: NEXT STEP TEST
R: REPEAT TEST OF SAME STEP
I: INSERT RANDOM STEPS
K: DELETE RANDOM STEPS
C: CHANGE OF RANDOM STEP
A: ERROR SET OF EACH PART
E: END (MODIFY, INSERT, TEST)

KEY-IN COMMAND & STEP No. (ex. D1 [RETURN]) T

0005,J0001,001,010, ,9.99 o,10%,1,D4,0,0
0006,S0002,005,009, ,9.99 o,10%,1,A2,0,0
0007,L0005,011,022, ,2.50mH,25%,4,E0,0,0
0008,R0002,010,020,030,26.7ko,15%,5,B7,5,0
0009,R0003,055,066,077,46.0ko,15%,5,A9,9,0

CONTROLLER NOT READY !!

0010,C0012,033,045,060,2.30mF,0x3,7,F0,0,0
0014,C0020,004,003,000,659.pF,20%,3,B6,1,0
0015,R0015,020,011,035,0.92ko,15%,4,C4,2,0
0016,T0002,031,020, ,710. o,10%,3,B3,1,0
0017,D0009,044,051,001,605. o,15%,3,F9,3,0
0018,R0023,016,040,032,35.7 o,20%,2,A2,F,0

PF4	PF5	PF6	PF7	PF8	PF9	PF10	PF15
SPACE	k	M	p	n	u	m	ABCD#

When conducting an execution (T, N, R) for the first time, "CONTROLLER NOT READY" is displayed. When this appears carry-out the ON LINE and TEST START operations.

The following figure is an example of executing step number 7 of the T command.

```
***** MAINTENANCE & MODIFY *****  
  
D:  DISPLAY 15 LINES FROM RANDOM STEP  
T:  TEST OF RANDOM STEP  
N:  NEXT STEP TEST  
R:  REPEAT TEST OF SAME STEP  
I:  INSERT RANDOM STEPS  
K:  DELETE RANDOM STEPS  
C:  CHANGE OF RANDOM STEP  
A:  ERROR SET OF EACH PART  
E:  END < MODIFY, INSERT, TEST >  
  
KEY-IN COMMAND & STEP No. < ex. D1 [RETURN] > T7  
  
0007  L0005, 011, 022,      ,2.50mH, 25%, 4,E0, 0, 0  
      MEASURED VALUE = 0.06mH  
  
PF4  PF5  PF6  PF7  PF8  PF9  PF10  PF15  
SPACE k  M  p  n  u  m  ABCD#
```

3.5 Operation of R command

This command is used at the time when the current step number is measured and executed repeatedly. (when displayed, the first step No.)

The following figure is an example of repeatedly executing step "7" from the previous page.

```
***** MAINTENANCE & MODIFY *****  
  
D:  DISPLAY 15 LINES FROM RANDOM STEP  
T:  TEST OF RANDOM STEP  
N:  NEXT STEP TEST  
R:  REPEAT TEST OF SAME STEP  
I:  INSERT RANDOM STEPS  
K:  DELETE RANDOM STEPS  
C:  CHANGE OF RANDOM STEP  
A:  ERROR SET OF EACH PART  
E:  END < MODIFY, INSERT, TEST >  
  
KEY-IN COMMAND & STEP No. < ex. D1 [RETURN] > R  
  
0007  L0005, 011, 022,      ,2.50mH, 25%, 4,E0, 0, 0  
      MEASURED VALUE = 0.21mH  
      MEASURED VALUE = 0.23mH  
      MEASURED VALUE = 0.23mH  
      MEASURED VALUE = 0.24mH  
      MEASURED VALUE = 0.82mH  
      MEASURED VALUE = 0.24mH  
      MEASURED VALUE = 0.23mH  
      MEASURED VALUE = 0.23mH  
      MEASURED VALUE = 0.24mH  
      MEASURED VALUE = 0.23mH  
      MEASURED VALUE = 0.23mH  
  
PF4  PF5  PF6  PF7  PF8  PF9  PF10  PF15  
SPACE k   M   p   n   u   m       ABCD#
```

842941

The following is an example of changing the same step number after the execution of R command with C command mentioned on the previous page. This too, is an example of the operation of C RETURN.

***** MAINTENANCE & MODIFY *****

D: DISPLAY 15 LINES FROM RANDOM STEP
T: TEST OF RANDOM STEP
N: NEXT STEP TEST
R: REPEAT TEST OF SAME STEP
I: INSERT RANDOM STEPS
K: DELETE RANDOM STEPS
C: CHANGE OF RANDOM STEP
A: ERROR SET OF EACH PART
E: END (MODIFY, INSERT, TEST)

KEY-IN COMMAND & STEP No. (ex. D1 [RETURN]) C

0007,L0005;011,022, ,2.50mH,25%,4,E0,0,0
0007,

PF4	PF5	PF6	PF7	PF8	PF9	PF10		PF15
SPACE	k	M	p	n	u	m		ABCD#

3.6 Operation of N command

This command is used for the measurement and execution of the next step.

The following figure is an example of where step "8" is executed with N command after the correction of step "7" mentioned on the previous page.

```
***** MAINTENANCE & MODIFY *****

D:  DISPLAY 15 LINES FROM RANDOM STEP
T:  TEST OF RANDOM STEP
N:  NEXT STEP TEST
R:  REPEAT TEST OF SAME STEP
I:  INSERT RANDOM STEPS
K:  DELETE RANDOM STEPS
C:  CHANGE OF RANDOM STEP
A:  ERROR SET OF EACH PART
E:  END ( MODIFY, INSERT, TEST )

KEY-IN COMMAND & STEP No. ( ex. D1 [RETURN] ) N

0000  R0002, 010, 020, 030,26.7ko, 15%, 5,B7, 5, 0
      MEASURED VALUE = 99.90o

PF4  PF5  PF6  PF7  PF8  PF9  PF10  PF15
SPACE k  M  P  n  u  m          ABCD#
```

842943

3.7 Operation of I command

This command is used for insertion into any step. For instance, I18 is input when inserting between step 17 and step 18.

After insertion, a new step 18 is created and step numbers for step 19 onwards are automatically adjusted and corrected.

After the insertion of one step, the next step number appears automatically so that insertion may be continued.

To end insertion, input "E" when the cursor is flickering at the position of the first letter of the part No.

The following is an example for insertion between step 17 and step 18. When I18 is input, the current contents of step 18 is indicated as an example (ex).

```
***** MAINTENANCE & MODIFY *****

D:  DISPLAY 15 LINES FROM RANDOM STEP
T:  TEST OF RANDOM STEP
N:  NEXT STEP TEST
R:  REPEAT TEST OF SAME STEP
I:  INSERT RANDOM STEPS
K:  DELETE RANDOM STEPS
C:  CHANGE OF RANDOM STEP
A:  ERROR SET OF EACH PART
E:  END < MODIFY, INSERT, TEST >

KEY-IN COMMAND & STEP No. < ex. D1 [RETURN] > I18
ex. 0010,R0023,016,040,032,35.7 o,20%,2,A2,F,0
    0018,
```

PF4	PF5	PF6	PF7	PF8	PF9	PF10	PF15
SPACE	k	M	p	n	u	m	ABCD#

842944

3.8 Operation of K command

This is the command to delete any step. The step number is automatically altered after deletion. To delete a step number, input the first and last numbers. In the case where only one step is to be deleted, just input that step number.

The following is an example for deletion between step 19 and 21.

```
***** MAINTENANCE & MODIFY *****  
  
D:  DISPLAY 15 LINES FROM RANDOM STEP  
T:  TEST OF RANDOM STEP  
N:  NEXT STEP TEST  
R:  REPEAT TEST OF SAME STEP  
I:  INSERT RANDOM STEPS  
K:  DELETE RANDOM STEPS  
C:  CHANGE OF RANDOM STEP  
A:  ERROR SET OF EACH PART  
E:  END ( MODIFY, INSERT, TEST )  
  
KEY-IN COMMAND & STEP No. ( ex. D1 [RETURN] ) K  
KEY-IN START STEP NUMBER FOR DELETE ? 19  
KEY-IN END STEP NUMBER FOR DELETE ? 21  
  
DELETING !!  
  
PF4 PF5 PF6 PF7 PF8 PF9 PF10 PF15  
SPACE k M p n u m ABCD#
```

842945

3.9 Operation of A command

This is a command to change the error setting value according to the part type in all the steps resistance, inductance, transistor and diode. ($\pm 1\% \sim \pm 99\%$)

The criterion for short and jumper is 9.99 Ω , so they are not at all related with the setting of errors.

In case the setting varies in each step, change the data with the C command as previously explained.

After the program is averaged and the execution file is *generated*, all the steps have $\pm 10\%$ as initial values.

The following is an example for setting the parts accordingly. Simply press RETURN for a part requiring no change. In the following example, inductance has no change. For values input 2 digits ("05" in case of "5").

```
***** MAINTENANCE & MODIFY *****

D:  DISPLAY 15 LINES FROM RANDOM STEP
T:  TEST OF RANDOM STEP
N:  NEXT STEP TEST
R:  REPEAT TEST OF SAME STEP
I:  INSERT RANDOM STEPS
K:  DELETE RANDOM STEPS
C:  CHANGE OF RANDOM STEP
A:  ERROR SET OF EACH PART
E:  END ( MODIFY, INSERT, TEST )

KEY-IN COMMAND & STEP No. ( ex. D1 [RETURN] ) A

      ERROR SET ( 1 - 99 )
      R ----- 10 %
      C ----- 25 %
      L -----  %
      T ----- 15 %
      D ----- 15 %

      ERROR SET OK ? ( Y or N )

PF4  PF5  PF6  PF7  PF8  PF9  PF10  PF15
SPACE k  M  P  n  u  m  ABCD#
```

3.10 Operation of E command

There are 3 types of uses for the end command.

- 3.10.1 To temporarily stop correcting while changing contents of any step with C command, input "E" when the cursor is flickering at the position of the first letter of the part number.
- 3.10.2 To stop step insertion with the I command, input "E" in the same way as for C command.
- 3.10.3 To stop the maintenance & correction program, input "E" at the same cursor position as for the other commands mentioned above, and the program will end with the following display. To return to the menu display, input "Y". When "N" is input, the maintenance & correction program is executed again from the start. When "E" is input to end this program, the instrument turns off (in the case of an air press, the press portion lifts, and in case of a vacuum instrument, the printed circuit board detaches itself). As the final data is contained in the work file, to turn off the machine, return to the menu display. To retain data completely, always input "E" at the time of end of the program.

When the program is stopped at , etc. without inputting "E", data retainment and the turning off of the instruments cannot be achieved.

In such a situation, continue the program with CONT and then end the program by inputting "E".

RETURN TO [MENU DISPLAY] ? < Y or N > ? Y

842947