


OPERATION MANUAL

AC Withstanding Voltage Tester

TOS8030



DANGER

This instrument generates high voltage.

- Any incorrect handling may cause death.
- Read “Precautions for Safe Testing” in this manual to prevent accident.
- Keep this manual near the instrument for easy access of the operator.

Use of Operation Manual

Please read through and understand this Operation Manual before operating the product. After reading, always keep the manual nearby so that you may refer to it as needed. When moving the product to another location, be sure to bring the manual as well.

If you find any incorrectly arranged or missing pages in this manual, they will be replaced. If the manual gets lost or soiled, a new copy can be provided for a fee. In either case, please contact Kikusui distributor/agent, and provide the “Kikusui Part No.” given on the cover.

This manual has been prepared with the utmost care; however, if you have any questions, or note any errors or omissions, please contact Kikusui distributor/agent.

Reproduction and reprinting of this operation manual, whole or partially, without our permission is prohibited.

Both unit specifications and manual contents are subject to change without notice.

Testing Cannot be Performed at Unpacking

If the TOS8030's power is turned on in the condition in which the tester has been simply unpacked upon receipt, the interlock function will be activated, preventing performance of testing as-is. See "6.2 Using the INTERLOCK Terminal" (page 42) to operate the tester, taking advantage of the interlock function.

■ About this manual

This documentation is the Operation Manual for the TOS8030 AC Withstanding Voltage Tester.

Firmware version of the product to be used:

This Operation Manual applies to products incorporating firmware of:

Version 1.0x

The firmware version is indicated on the voltmeter when the POWER switch is turned on pressing the STOP switch. For more information, see "5.1 Turning the POWER Switch On" (page 30).

When inquiring about the product, please provide this version number and the serial number indicated on the rear of the product.

To the Supervisor in Charge of Operation

- If the operator does not read the language used in this manual, translate the manual into the appropriate language.
- Help the operator in understanding this manual before operation.
- Keep this manual near the instrument for easy access by the operator.

Hazardous Operations

Any of the following operations will result in electric shock, which may lead to serious injury or death.

- Touching the output terminal while output is being generated.
- Touching a test lead connected to the output terminal while output is being generated.
- Touching the DUT while output is being generated.
- Touching a part electrically connected to the output terminal while output is being generated.

Any of the following actions may result in electric shock leading to serious injury or death.

- Operating the tester without connecting the grounding wire to ground.
- Operating the tester without wearing rubber gloves intended for electrical work.
- Approaching a section electrically connected to the output terminal while output is being generated.

Safety Symbols

For the safe use and safe maintenance of this product, the following symbols are used throughout this manual and on the product. Understand the meanings of the symbols and observe the instructions they indicate (the choice of symbols used depends on the products).

	Indicates that a high voltage (over 1 000 V) is used here. Touching the part causes a possibly fatal electric shock. If physical contact is required by your work, start work only after you make sure that no voltage is output here.
DANGER	Indicates an imminently hazardous situation which, if ignored, will result in death or serious injury.
	Indicates a potentially hazardous situation which, if ignored, could result in death or serious injury.
	Indicates a potentially hazardous situation which, if ignored, may result in damage to the product and other property.
	Shows that the act indicated is prohibited.
	Is placed before the sign “DANGER,” “WARNING,” or “CAUTION” to emphasize these. When this symbol is marked on the product, see the relevant sections in this manual.
	Protective conductor terminal.
	Chassis (frame) terminal.
	On (supply)
○	Off (supply)
	In position of a bi-stable push control
	Out position of a bi-stable push control

Safety Precautions

The following safety precautions are intended to avoid fire hazard, electrical shock, and other accidents or failures. Use of the product in a method not specified in this manual may impair the effectiveness of built-in protective functions.




Users

- This product must be used only by qualified personnel who understand the contents of this Operation Manual.
- If this product is handled by unqualified personnel, personal injury may result. Ensure that the product is handled under the supervision of qualified personnel (i.e., those experienced in electrical applications).



Purposes of use

- Do not use the product for any purpose other than those specified.
- This product is not designed or manufactured for home use or for general consumers.




Input power

- Always connect the product to a power supply in line with the product's input rating.
- Use the provided power cord to supply input power.
- This product is designed as equipment falling under Overvoltage Category II of the IEC Standards (energy-consuming equipment to be supplied from fixed installation).




Cover

- Components inside the instrument may present physical hazards. Do not remove the external cover.



Grounding

- The product is equipment falling under Safety Class I of the IEC Standards (equipment with a protective conductor terminal). Always ground the product's protective conductor terminal to prevent electric shock.



Installation

- This product is designed for indoor use. Only use it indoors.
- When installing products be sure to observe "2.2 Precautions for Installation" described in this manual.



Relocation

- Turn off the POWER switch and disconnect all cables before relocating the product.
- Be sure the operation manual be included when the product is relocated.



Operation

- Before using the tester, check that there are no abnormalities on the surface of the power cord. (Before doing this, always disconnect the power cord from the electrical outlet.)
- If any abnormality or failure is detected in the products, stop using it immediately. Unplug the power cord. Be careful not to allow the product to be used before it is completely repaired.
- Do not disassemble or modify the product. If it must be modified, contact Kikusui distributor/agent.



Maintenance and checking

- To avoid electrical shock, be absolutely sure to unplug the power cord before performing maintenance or checking.
- Do not remove the cover when performing maintenance or checking.
- To maintain performance and safe operation of the product, it is recommended that periodic maintenance, checking, cleaning, and calibration be performed.



Service

- Internal service is to be done by Kikusui service engineers. If the product must be adjusted or repaired, contact Kikusui distributor/agent.

Safety Precautions (Continued)

Label

- The product carries a label providing important safety information. If this label is damaged or the information provided becomes illegible, replace it with a new label. To obtain a new label, please contact your Kikusui distributor or agent.



危険 DANGER 危険
高电压 High Voltage 高电压

本仪器输出过程中，为了防止触电事故的发生，请严格遵守以下操作规程：

- (1) 不要触摸输出端子。
- (2) 不要触摸连接输出端的测试线。
- (3) 不要触摸被测体。
- (4) 输出切断后，请不要立刻触摸以上部分。

如果不遵守上述注意事项，有可能发生重大的人身事故。
在使用之前，请仔细阅读使用说明书。

While tester is generating output:

- (1) **Do not touch** output terminal.
- (2) **Do not touch** lead-wire connected with output terminal.
- (3) **Do not touch** device under test.
- (4) **Do not touch** such parts immediately after output is cut off.

Failure to do so could result in **serious injury or death.**
Read OPERATION MANUAL before operating.

本器が出力中は、感電事故防止のため次の事をお守り下さい。

- (1) 出力端子に触らない。
- (2) 出力端子に接続されているリード線に触らない。
- (3) 被試験物に触らない。
- (4) 出力遮断後すぐに、(1)~(3)の部分に触らない。

上記事項を守らない場合、人命にもかわる重大な事故となることがあります。
ご使用になる前に、取扱説明書をお読み下さい。

**后盖警告**

绝对不能拆卸本仪器外壳。
装拔电源线时，必须将插头拔下或者关闭配电箱的总电源。
为了防止触电事故，必须把电源线的保护接地线连接到地线上再使用。


**WARNING**

DO NOT REMOVE COVERS, REFER SERVICING TO QUALIFIED PERSONNEL. SECURELY DISCONNECT THE POWER CORD FROM THE AC OUTLET OR SWITCHBOARD BEFORE HANDLING THE POWER CORD.

TO AVOID AN ELECTRIC SHOCK, THE POWER CORD PROTECTIVE CONDUCTOR TERMINAL MUST BE CONNECTED TO AN ELECTRICAL GROUND.



**警告**

本器のカバーは、絶対に取り外してはいけません。
電源コードの取り扱いは、必ず電源プラグを抜くか配電盤からの給電を遮断してから行って下さい。
感電事故防止のため、電源コードの保護導体端子を必ず接地してご使用下さい。



Front and rear panels

- Before using the tester, make sure you read and understand Chapter 3, “Precautions for Safe Testing.”



Organization of the Operation Manual

The information in this manual is organized into the following chapters:

Chapter 1 General

Provides a product overview and describes features and options.

Chapter 2 Installation and Preparations for Use

Describes how to unpack the tester for preparation before use.

Chapter 3 Precautions for Safe Testing

Gives the precautions to be observed at all times to ensure safe testing.

Chapter 4 Part Name's and Functions

Gives the names of switches, terminals, and other controls of the TOS8030.

Chapter 5 Panel Operations

Describes procedures for testing.

Chapter 6 Remote Control

Gives the procedure for operating the tester from a remote location using the REMOTE connector and the INTERLOCK terminal.

Chapter 7 Status Signal Output

Describes the status signal outputs (SIGNAL OUT).

Chapter 8 Maintenance and Calibration

Describes the maintenance and calibration of the tester. The tester must be periodically inspected, maintained, and calibrated to maintain performance.

Chapter 9 Specifications

Provides the electrical and mechanical specifications for the TOS8030.

Appendix

Provides guidelines for zero-start switch.

Contents

Testing Cannot be Performed at Unpacking	1
To the Supervisor in Charge of Operation	2
Hazardous Operations	2
Safety Symbols	3
Safety Precautions	4

Chapter 1 General

1.1 Product Overview	11
1.2 Features	11
1.3 Options	12

Chapter 2 Installation and Preparations for Use

2.1 Unpacking Inspection	14
2.2 Precautions for Installation	15
2.3 Moving Precautions	16
2.4 Connecting the Power Cord	16
2.5 Grounding	18

Chapter 3 Precautions for Safe Testing

3.1 Startup Inspection	19
3.2 Preparations Before Testing	19
3.2.1 Checking the Test Leads	19
3.2.2 Wearing Rubber Gloves	19
3.3 Operating Precautions	20
3.3.1 Connecting the Test Leads	20
3.3.2 For High Voltage Output	22
3.3.3 Checking Safety after Shutting off the Output	23
3.4 When Interrupting Operations	24
3.5 Response to Emergencies	24
3.6 Stop Using the Tester in the Event of a Malfunction	25

Chapter 4 Part Name's and Functions

4.1 Front Panel	26
4.2 Rear Panel	29

Chapter 5 Panel Operations

5.1 Turning the POWER Switch On	30
5.2 Tester States and Indications	31
5.2.1 Five States	32

5.2.2	Events or Conditions That Can Activate the Protection Function	- -33
5.3	Procedure for Test	- -34
5.3.1	Test Parameters	34
5.3.2	Connection to the DUT	-37
5.3.3	Starting the Test and Making Judgments	37
Chapter 6 Remote Control		
6.1	Using the REMOTE Connector	-38
6.1.1	Remote Control with the Optional Remote Control Box	38
6.1.2	Remote Control Using a Control Device	-39
6.2	Using the INTERLOCK Terminal	-42
Chapter 7 Status Signal Output		
7.1	Five Signal Outputs	-43
7.2	Using the SIGNAL OUT Terminals	-43
7.2.1	Description of the Terminals	43
7.2.2	Example: Use of Signals	-44
Chapter 8 Maintenance and Calibration		
8.1	Cleaning the Tester	-45
8.2	Inspection	-45
8.3	Calibration	-45
Chapter 9 Specifications		
9.1	Basic Specifications	-46
9.2	Other Functions	-48
9.3	General Specifications	-48
9.4	Dimensions	-49
Appendix		
A.1	Improvements in Waveform Obtained Using a Zero-start Switch	-50
Index		51

Provides a product overview and describes features and options.

1.1 Product Overview

This instrument is a withstanding voltage tester with a maximum output of 3 kV/10 mA. It is capable of performing withstanding voltage (dielectric strength) tests for any electronic component or device*.

NOTE

* The TOS8030 withstanding voltage tester was designed based on a product concept of lightweight portability. As such, please check the specification requirements for the relevant standards when using the tester to test electronic devices based on JIS, UL, or other standards. It is possible that the tester will not meet some of the specification requirements.

⚠ WARNING

• Note to the supervisor in charge of operation, and operator
The utmost care has been devoted to making this tester as safe as possible. However, accidental contact with the device under testing (DUT), test lead, test probe, or the periphery of the output terminals may result in electric shock, since high voltage is applied to the DUT during tester operations. Thus, use of the tester requires thorough safety measures, including provision of fences at the peripheries of the tester and DUT to prevent personnel from approaching without good reason and to maintain safety.

1.2 Features

■ Compact and lightweight

Dimensions: 160 W x 132 H x 230 D mm

Weight: Approx. 6 kg

The tester can be easily transported holding the grip on the top face of it.

■ Judgment reference value of 0.1 mA to 11 mA (x0.1 / x1 range)

A current value used as judgment criteria can be set in the range of 0.1 mA to 11 mA. Particularly, from 0.1 mA to 9.9 mA (x0.1 range), it can be set in 0.1 mA steps.

It is capable of high-sensitivity and high-resolution detection, making it suitable for withstanding voltage testing of electronic components.

■ Test time of 0.5 s to 99 s (x0.1 / x1 range)

The test time can be set to a duration in the range from 0.5 s to 99 s, and in 0.1 s intervals in the range from 0.5 s to 9.9 s (x0.1 range).

■ Displaying the cause of activation of the protective function as a code number

If the protective function is activated, the cause is given as a code number via the voltmeter. A code number is also indicated if there are discrepancies in setting test conditions, allowing you to promptly correct the setting based on the code number displayed.

■ Remote control

The optional remote control box or test probe allows testing to be started or stopped remotely.

■ Status signal output

The tester has output terminals for READY, H.V ON, PASS, FAIL, and PROTECTION signals to enable external monitoring of tester status.

Use this function with the remote control function to automate functions or to reduce actual hands-on testing requirements.

■ Sequence circuit with noise reduction features

For reliability, the sequence circuit incorporates thorough noise reduction features to prevent noise-induced malfunctions.


1.3 Options

Remote Control Boxes


Connecting a remote control box to the REMOTE connector of our Withstanding Voltage Testers, Insulation Resistance Testers, or Withstanding Voltage Insulation Resistance Testers, enables remote starting or stopping of testing.

The RC01-TOS has one START switch; the RC02-TOS has two START switches. With the RC02-TOS remote control box, testing can be started only when both START switches are pressed simultaneously.

Description of RC01-TOS/RC02-TOS	
OPERATE switch	The START switch is enabled only when this switch is ON. Turning this OFF halts testing.
START switch	When the OPERATE switch is ON and the tester is in a READY state, press this switch to begin testing.
STOP switch	This switch shuts off the output voltage or cancels a status (such as FAIL). It has the same function as the STOP switch on the tester.



RC01-TOS
200(W) x 70(H) x 39(D) mm




RC02-TOS
330(W) x 70(H) x 39(D) mm

High-voltage test probes

The HP01A-TOS and HP02A-TOS are test voltage output probes designed to be connected to our withstanding voltage tester.

The test probes are constructed so that a test voltage is output only when the slide lever at the grip of a test probe is held and the trigger is activated with one hand, and a switch on the upper part of the probe is pressed with the other; that is, operation requires two hands. Releasing either hand outputs a STOP signal, shutting off the tester's test voltage.

This features are intended to prevent inadvertent output of test voltages when using these probes.



HP01A-TOS

Model number	Maximum usage voltage	Cable length
HP01A-TOS	4 kVac (rms) 50 Hz/60 Hz	Approx. 1.8 m
HP02A-TOS	5 kVdc	Approx. 3.5 m

-
- ⚠ WARNING** • When using a test probe, do not connect it to the DUT while a test voltage is being output from the probe. Also, do not disconnect the probe from the DUT while a test voltage is being output from the probe.

Disconnecting the probe from the DUT while high voltage is being output from the probe may result in damage to the DUT. Additionally, disconnecting the probe from the DUT in the middle of testing may result in a residual electrical charge in the DUT, posing a significant hazard.

For these reasons, the probe must be connected to the DUT before testing begins. When ending the test, confirm that the LED on the probe is not lit, then disconnect the probe from the DUT.

High-voltage test leads


Model number	Maximum usage voltage	Cable length	Remarks
TL01-TOS	5 kVac (rms) 50 Hz/60 Hz	Approx. 1.5 m	Equivalent of TOS8030 accessory
TL02-TOS	5 kVdc	Approx. 3.0 m	

Chapter 2 Installation and Preparations for Use

Describes how to unpack the tester for preparation before use.

2.1 Unpacking Inspection

Check the TOS8030 tester upon receipt for any damage that may have occurred during transit and to confirm that all accessories have been provided. If the product is damaged or if any accessories are missing, notify your Kikusui distributor or agent.




The power cord that is provided varies depending on the destination for the product at the factory-shipment.

Plug: NEMA5-15
Rating: 125V/10A
[85-AA-0003]


Plug: CEE7/7
Rating: 250V/10A
[85-AA-0005]

Plug: GB1002
Rating: 250V/10A
[85-10-0790]


Power cord, 1



High-voltage test leads, 1 set
TL01-TOS, 1.5 m



INTERLOCK terminal jumper, 1



[Z1-AB0-072]

Operation Manual, 1 copy

Fig.2-1 Accessories

NOTE

- We recommend retaining all packing materials in case the product needs to be transported at a later date.
-

2.2 Precautions for Installation

Always observe the following precautions and conditions when installing the tester indoors:

■ **Do not use the tester in a flammable atmosphere.**

To prevent explosions or fires, never use the tester near combustible materials such as alcohol or thinner or in an atmosphere containing such vapors.

■ **Avoid locations subject to high temperatures or exposed to direct sunlight.**

Do not locate the tester near a heater or in areas subject to drastic temperature fluctuations.

Operating temperature range: 0°C to +40°C

Storage temperature range: -40°C to +70°C

■ **Avoid humid locations.**

Do not install the tester in high-humidity locations, including near boilers, humidifiers, or water supply.

Operating relative humidity range: 20% to 80% (with no dew condensation)

Storage relative humidity range: 90% or less (with no dew condensation)

Condensation may occur even within the operating relative humidity range. If so, do not use the tester until it is completely dry.

■ **Do not install the tester in a corrosive atmosphere.**

Do not install the tester in a corrosive atmosphere or in an atmosphere containing sulfuric acid mist or the like. Doing so may result in corrosion of conductors or improper connector contacts in the tester, resulting in malfunctions or failures and leading to potential fires.

■ **Do not install the tester in locations with excessive dust.**

Excessive dirt and dust may result in electric shock or fire.

■ **Do not use the tester in areas with poor ventilation.**

The tester uses an unforced air cooling system. Provide adequate space around the tester.

■ **Do not place any objects on the tester.**

In particular, heavy objects placed on the tester may lead to malfunctions.

■ **Do not install the tester on tilted surfaces or in locations subject to vibration.**

The tester may fall, resulting in damage or injury.

■ **Do not use the tester in locations subject to strong magnetic or electric fields.**

Using the tester in such locations may result in malfunctions, leading to electric shock or fire.

- **Do not use the tester in locations where sensitive measuring instruments or receivers are also being used.**

Use of the tester may affect the reliability or accuracy of such instruments or devices.

At a test voltage of more than 3 kV, corona discharges may occur that result in significant wide-range RF emissions between the clips of the test leads. To minimize these effects, keep the alligator clips as far apart as possible. Never allow an alligator clip or test lead to contact or approach the conductor surface (especially sharp metal ends).

- **Provide sufficient space around the power plug.**

Do not use excessive force to insert the power plug into an electrical outlet that resists insertion/extraction. Do not install objects near the plug that make plug insertion/extraction difficult.

2.3 Moving Precautions

When moving or transporting the tester to another installation site, observe the following precautions:

- **Turn the POWER switch off.**

Moving the tester with the power turned on may result in electric shock or damage.

- **Disconnect all wiring.**

Moving the tester with cables connected may result in breaks in the cables or may cause the tester to fall, which could result in injury.

- **When transporting the tester, always use the dedicated packing materials.**

Failure to use the dedicated packing materials may result in damage to the tester in the event of a fall or due to vibrations during transport.

- **Be sure the operation manual be included.**

2.4 Connecting the Power Cord

This product is designed to meet the standards for Overvoltage Category II (energy-consuming equipment to be supplied from fixed installation) of the IEC standards.

Checking the supply voltage

Before connecting the power cord, check the tester's supply voltage (100 V or 220 V). The tester's nominal input rating is indicated on the rear panel.

LINE VOLTAGE	FREQUENCY	VA MAX
100V	50/60Hz	50VA

Check the indicated voltage in this field.

-
- ⚠ CAUTION** • For the nominal input rating, the input voltage range for the tester to be able to operate correctly is required. Use beyond the input voltage range may result in malfunction or failure in addition to improper operation. Operate the tester with the supply voltage within the voltage range required. The waveform of the power source should be a sine wave having a peak value within 130% to 150% of the rms value. For information on the input voltage range to the nominal input rating, see “General Specifications” (page 48).
-

- NOTE** • The tester’s maximum rated output (3 kV at 10 mA) is specified at the nominal input rating. When the input voltage is less than the nominal input rating, the maximum rated output is not assured.
-

The tester is equipped with a high voltage output transformer of 30 VA. In the following two instances, large currents (several tens of amperes) may flow in the AC power line to which the tester is connected.

- A period of several tens of milliseconds during which the tester detects a FAIL judgment if the DUT is judged FAIL.
- The instant at which testing is conducted

In such cases, take into account the capacity of the AC power line and the power consumption of other electronic devices connected to that power line.

Connecting the power cord

-
- NOTE** • The power cord is a disconnecting device that disconnects the tester from the AC power line. Connect it to an easily accessible electrical outlet.
- Do not use the power cord provided with the product as a power cord for other equipment.
-

1. Check that the power supply meets the nominal input rating for the tester.
2. Turn the POWER switch off.
3. Connect the power cord to the AC INPUT connector on the tester’s rear panel.
4. Insert the power cord plug into an electrical outlet.

2.5 Grounding

Ground the tester by connecting the power cord to a properly grounded three-prong electrical outlet.




Fig. 2-2 Protective Conductor Terminal

⚠ WARNING • This product is Safety Class I equipment (equipment with a protective conductor terminal) under IEC Standards. To prevent electric shock, always connect the product's protective conductor terminal to an electrical ground (safety ground).

■ Grounding is essential.

If the tester is used without grounding and output is inadvertently short-circuited to peripheral equipment such as a conveyor connected to ground or a nearby AC power line*, the tester's enclosure may be charged to hazardous voltages.

However, when the tester is properly grounded, it will not malfunction, and its enclosure will not be charged to high voltages even if the output is short-circuited to the ground via a peripheral, as noted above, or if the tester's LOW terminal and HIGH VOLTAGE terminal are short-circuited.

For these reasons, grounding the tester is essential to ensure safety.

Description * An AC power line is generally a power line connected to an electrical outlet to which the tester's power cord is connected. Here, it also refers to an AC line connected to a privately-owned electrical power generation device.

Gives the precautions to be observed at all times to ensure safe testing.

-
- ⚠ WARNING** • This tester supplies voltages as high as 3 kVAC or more to an external device during testing. Misuse may result in injury or death. To prevent such accidents, always observe the precautions given in this chapter. Use the tester with the utmost care and regard for safety.
-

3.1 Startup Inspection

Check the following items before testing:

Item	Description of inspection	Refer to:
Grounding	Confirm that the power cord has been connected to a properly grounded three-prong electrical outlet.	“2.5, Grounding” (page 18)
High-voltage test leads	Check for breaks, cracks, or other defects in the covering and for broken wires.	“3.2.1, Checking the Test Leads” (page 20)
Displays and indicators	Confirm that all the displays and indicators light.	“5.1, Turning the POWER Switch On” (page 30)

3.2 Preparations Before Testing

3.2.1 Checking the Test Leads

Check for breaks, cracks, or other defects in the covering of the LOW-side test lead (black) and HIGH VOLTAGE-side test lead (red).

Use a tester to confirm that there are no broken wires in the test leads.

3.2.2 Wearing Rubber Gloves

-
- ⚠ WARNING** • When using the tester, always wear rubber gloves intended for electrical work to prevent electric shock.
-

If you have difficulty obtaining proper rubber gloves, consult your Kikusui distributor or agent.

3.3 Operating Precautions

3.3.1 Connecting the Test Leads

When connecting the test leads, observe the procedure given below to ensure secure connections.

1. Check the indications at the two locations shown in Fig. 3-1.




Fig. 3-1 Checking that No High Voltage is Being Output

2. Insert the black test lead into the LOW terminal and attach an extraction prevention guard to the terminal, as shown in Fig. 3-2.




Fig. 3-2 Connecting the LOW-side Test Lead

3. Connect the black test lead to the DUT.

Note that improper test-lead connections may cause the entire DUT to be charged to dangerously high voltages.

4. Connect the red test lead to the DUT.




Fig. 3-3 Example of Connection to the DUT

5. Insert the red test lead into the HIGH VOLTAGE terminal.




Fig. 3-4 Connecting the HIGH VOLTAGE-side test lead

■ To disconnect the test leads from the DUT

Disconnect the red test lead from the HIGH VOLTAGE terminal. You do not need to disconnect the black test lead from the LOW terminal.

3.3.2 For High Voltage Output

The TEST lamp goes on during testing. In this case, the DANGER lamp also lights up, alerting the operator that high voltages are being output.




Fig. 3-5 Indicators Lit during Testing

When the DANGER lamp is lit



- **Do not touch the DUT, test lead, test probe, or any high-voltage-charged sections at the periphery of the output terminals.**

Contact with any of these areas may result in electric shock.

Never attempt to touch the PVC covering of the alligator clip of a test lead. (The dielectric strength is inadequate to prevent shock.)

During testing, never attempt to touch the alligator clip of a test lead.




Fig. 3-6 Test Lead

- **Do not leave the tester while it is operating.**

A person who operates the tester must remain with it until the test is complete. If he/she must leave the tester, always turn the POWER switch off.

- **Do not turn the POWER switch off.**

Except in emergencies, do not turn the POWER switch off while output is being generated.

3.3.3 Checking Safety after Shutting off the Output

■ Checking indications at two locations

If you must touch the DUT, test lead, test probe, and/or a high-voltage-charged section such as the periphery of the output terminals for re-installing wiring, etc., check the indications at the two locations shown in Fig. 3-7 to ensure safety.




Fig. 3-7 Checking for the Absence of High Voltage

■ When disconnecting the test leads from the DUT

Disconnect the red test lead from the HIGH VOLTAGE terminal. You do not need to disconnect the black test lead from the LOW terminal.




Fig. 3-8 Disconnecting the HIGH VOLTAGE-side Test Lead

3.4 When Interrupting Operations

If the tester will not be used for certain periods or if the operator is to leave the tester, turn the TEST VOLTAGE knob all the way counterclockwise (to the MIN position), then turn the POWER switch off.




Fig. 3-9 When Interrupting Operations

3.5 Response to Emergencies

If electric shock occurs or the DUT is burned due to abnormalities in the tester, DUT, or other components, take the following two steps. Both must be performed, although either may be performed first.




Fig. 3-10 Response to Emergencies

3.6 Stop Using the Tester in the Event of a Malfunction

Any of the following tester conditions may result in serious and hazardous malfunctions in which the tester's output cannot be shut off while high voltage is output. In such cases, immediately stop using the tester, turn the POWER switch off, and disconnect the power plug from the outlet.

- 1 **The DANGER lamp remains lit even when the STOP switch is pressed.**
- 2 **The DANGER lamp does not light, but the voltage is displayed on the voltmeter.**

The cause of condition 2 may simply be a defective DANGER lamp. Nevertheless, immediately stop using the tester to guard against the possibility of malfunctions resulting electric shock.

Additionally, if the tester fails to operate normally, suspend use immediately. In certain cases, high voltages may be output regardless of operator intention.

-
-  **WARNING**
- Implement safeguards so that no one will attempt to use the tester before it has been sent for repair.
 - Always contact your Kikusui distributor or agent to request repairs. To ensure safety, never attempt to repair the product yourself.
-

Gives the names of switches, terminals, and other controls of the TOS8030.

4.1 Front Panel




Fig.4-1 TOS8030 Front Panel

[1] POWER switch

Turns the tester power on/off. Depressing the switch turns power on (|).
Before turning the POWER switch on, see “5.1 Turning the POWER Switch On” (page 30).

[2] STOP switch

This switch interrupts the test in progress.
Pressing this switch transitions the tester from PASS, FAIL, or PROTECTION to the READY state. Tester states are defined in “5.2.1 Five States” (page 32).

[3] START switch

Press this switch when the tester is in the READY state to perform testing under the current test conditions.

This switch is disabled for remote control operations.

[4] Indicators

Indicators indicate the selected test type and tester status. For more information, see “5.2 Tester States and Indications” (page 31).

TEST	Lights up when testing is in progress.
PASS	Lights up for approx. 200 ms if the test result is determined to be PASS.
FAIL	Lights up when the test result is determined to be FAIL.
PROTECTION	Lights up when the protective function is activated.

[5] CUTOFF CURRENT (mA)

Used to set the reference value of leakage current detection.

Select the range (x0.1 or x1) and set the reference value in the range of 0.1 mA to 11 mA.

For more information, see the "Current Detection Reference Value" item on page 34.

[6] DANGER lamp

Lights up when high voltages are being output.

This lamp remains lit not just during actual testing, but for the period after interruption or completion of testing during which the output terminals retain a high voltage.

⚠ WARNING • To prevent electric shock, always avoid contact with the DUT, test lead, test probe, and high-voltage-charged sections such as the periphery of the output terminals when the DANGER lamp is lit.

[7] LOW terminal

A low voltage terminal for outputting test voltages. Since it is connected directly to the chassis, grounding the protective conductor terminal of the power cord also grounds this terminal.

For more information, see “2.5 Grounding” (page 18).

[8] HIGH VOLTAGE terminal

A high voltage terminal for outputting test voltages

[9] Voltmeter

This voltmeter displays the output voltage, indicating the voltage at the HIGH VOLTAGE terminal.

If the tester enters the PROTECTION state, the voltmeter displays the reason for protective function activation by a code ranging from P01 to P12 (7 events).

[10] TEST VOLTAGE knob

Regulates the test voltage.

Turning the knob clockwise from the MIN position increases output voltage. Unless testing is being performed, always turn the knob to the counterclockwise limit position (to the MIN position).

For more information, see item “Test voltage” (page 35).

[11] TIMER

When the TIMER switch is turned ON, test time can be set.

Select the range (x0.1 or x1) and set test time in the range of 0.5 s to 99 s.

For more information, see item “Test time” (page 35).

4.2 Rear Panel




Fig. 4-2 TOS8030 Rear Panel

[1] REMOTE connector

Used to start or stop testing from a remote location.

For more information, see “Using the REMOTE Connector” (page 38).

[2] SIGNAL OUT terminal

Used to monitor the tester status externally.

There are five status terminals: READY, H.V ON, PASS, FAIL, and PROTECTION.

For more information, see “Chapter 7 Status Signal Output” (page 43).

[3] INTERLOCK terminal

An interlock signal terminal.

Opening this interlock signal terminal causes the tester to enter the PROTECTION state (P01), disabling testing.

For more information, see “6.2 Using the INTERLOCK Terminal” (page 42).

[4] BUZZER knob

Adjusts the volume of the buzzer that indicates a FAIL or PASS judgment.

Turning the knob clockwise makes the buzzer louder. The buzzer cannot be turned off.

[5] AC INPUT

An AC power input connector.

Connect the provided power cord to this connector.

For more information, see “2.4 Connecting the Power Cord” (page 16).

Describes procedures for testing.

5.1 Turning the POWER Switch On

1. Turn the TEST VOLTAGE knob all the way counterclockwise (to the MIN position), then turn the POWER switch on.




Fig.5-1 Check when Turning the POWER Switch On

2. Check that all display units and indications light appropriately.
 If for any reason you fail to check their status, turn the POWER switch off, wait several seconds, then turn on once again.
 After all the display units and indications light, the tester changes to display the test conditions currently set.




Fig. 5-2 Indications Displayed After POWER Switch is Turned On

■ Checking the firmware version

To check the firmware version, turn the POWER switch on pressing the STOP switch.

After all the display units and indications light, the firmware version is displayed in the voltmeter. The tester then changes to display the test conditions currently set.



After all the display units and indications light, the firmware version is displayed in the voltmeter.

Example of indication of version 1.00

Fig. 5-3 Firmware Version display

■ Do not turn the POWER switch on/off in quick succession.

After turning the POWER switch off, wait several seconds before turning it on again.

Never perform a rapid on/off cycle of the POWER switch. The tester's protection function may be unable to protect the tester under these conditions, resulting in electric shock or other problems.

Except during an emergency, never turn the POWER switch off while voltage is being output.

5.2 Tester States and Indications

The front panel's indicators indicate tester state.




Fig. 5-4 Indicators on the Front Panel

5.2.1 Five States

This tester recognizes five tester states: TEST, PASS, FAIL, PROTECTION, and READY, which are defined below:

■ TEST state

State from start of to suspension or completion of testing

The TEST and DANGER lamps remain lit to indicate that a test voltage is being output. An H.V ON signal is generated.

■ PASS state

Indicates a state in which testing has ended and the result has been determined to be PASS.

The PASS lamp lights, a buzzer sounds, and a PASS signal is generated to indicate a PASS state for approx. 200 ms. The tester then transitions to a READY state.

■ FAIL state

Indicates a state in which testing has ended and the result has been determined to be FAIL.

The FAIL lamp lights, a buzzer sounds, and a FAIL signal is generated to indicate a FAIL judgment. The FAIL state can be canceled by pressing the STOP switch, after which the tester transitions to a READY state.

■ PROTECTION state

Indicates a state in which the protection function is activated.

The PROTECTION lamp lights, and a PROTECTION signal is generated to indicate that the tester is in the PROTECTION state. A code representing the cause of protection function activation is also displayed on the voltmeter in this state. For more information, see “5.2.2 Events or Conditions That Can Activate the Protection Function” (page 33).

The PROTECTION state can be canceled by pressing the STOP switch (or by inputting a STOP signal), after which the tester transitions to a READY state.

■ READY state

A READY signal is generated in this state. All four lamps (TEST, PASS, FAIL, and PROTECTION) remain unlit.

Press the START switch in this state to start testing.

5.2.2 Events or Conditions That Can Activate the Protection Function

The following 7 events or conditions can activate the protection function. Each is assigned a unique code, which is displayed on the voltmeter.

If the protection function is activated, check the indicated code number and take appropriate measures in accordance with Table 5-1.

To clear the PROTECTION state, press the STOP switch.

-
- ⚠ WARNING** • If the PROTECTION lamp remains lit even after the event or condition activating the PROTECTION state has been removed and the STOP switch pressed, the tester may be defective. To ensure safety, immediately stop using the tester.
-

Table5-1 Events or Conditions Activating the Protection Function, and Remedies

Code Number	Possible Cause	Remedy
P01	The INTERLOCK terminal is open.	Take appropriate measures to close (short-circuit) the INTERLOCK terminal for the duration of the test.
P02	The test time has been set to a value of 0.4 s or less for a test involving the timer.	Set the test time to a value ranging from 0.5 s to 99 s.
P06	The value set for the reference value has exceeded 11 mA.	Set the reference value to a value ranging from 0.1 mA to 11 mA.
P07	The value set for the reference value is 0 mA.	Set the reference value to a value ranging from 0.1 mA to 11 mA.
P10	The REMOTE connector was inserted or extracted.	Turn the POWER switch off before connecting or disconnecting the plug to or from the REMOTE connector.
P11	The tester's internal temperature is too high.	Halt testing for a period equal to or longer than the test duration. For more information, see "Footnote *1" in "9.1 Basic Specifications" (page 46).
P12	A voltage of 3.6 kV or higher was output.	Adjust the output voltage to 3.0 kV or less using the TEST VOLTAGE knob.




Fig. 5-5 Example of Display of Code "P06"

5.3 Procedure for Test

5.3.1 Test Parameters


The following parameters must be set.

Set these values according to the standards of the withstanding voltage test to be performed.

Parameter	Range
Current detection reference value	0.1 mA to 11 mA
Test time	TIMER OFF, 0.5 s to 99 s
Test voltage	0.05 kV to 3.00 kV

Current detection reference value

If the measured leakage current exceeds the value set here, a FAIL determination is returned. Valid current values range from 0.1 mA to 11 mA. Setting the value to 0 mA or 11 mA or higher will cause the tester to enter a PROTECTION state (P07 or P06).



If the x0.1 mA range is selected,
"05" signifies a setting of 0.5 mA.

Fig. 5-6 Setting a Current Detection Reference Limit


NOTE

- If the operator sets a current value exceeding 5 mA, testing is subject to output time limitations. For more information, see "Footnote *1" in "9.1 Basic Specifications" (page 46).

Test time

When the time set here from the start of testing has elapsed, the test result is determined to be PASS, and the test is deemed complete. If the measured leakage current value exceeds the reference value, the test result is determined to be FAIL, even if the set test time has not yet expired, ending testing.

Valid test times range from 0.5 s to 99 s. Setting a test time of 0.4 s or less will invoke the PROTECTION state (P02).



If the x0.1 s range is selected, the "05" signifies a setting of 0.5 s.

Fig. 5-7 Setting the Test Time

For testing in which the test time will exceed 99 s or in which no test time will be set, move the TIMER switch to the OFF position.

If the timer is not used, no PASS judgment will be made.

Test voltage

The voltage set here is applied to the DUT during the test.

WARNING • The test voltage must be set by actually outputting the voltage and reading the value on the voltmeter. For safety reasons, disconnect the test leads if they are connected to the output terminals.

NOTE • The maximum output voltage of the tester at no-load rises above 3 kV. This value rises higher in proportion to power supply fluctuations, but it should always be set to a value ranging from 0.05 kV to 3.00 kV.

Test voltage (Continued)

1. Bring the tester to the state shown in Fig. 5-8.
If the PROTECTION lamp is lit, press the STOP switch to cancel PROTECTION.




Fig. 5-8 Preparing for Test Voltage Setup

2. Press the START switch.
3. Monitoring the indication on the voltmeter, gradually turn the TEST VOLTAGE knob clockwise to set the test voltage.
4. Press the STOP switch to shut off the output.

If timer was changed in step 1 to set the test voltage, return the settings to their original values.




Fig. 5-9 Setting the Test Voltage

5.3.2 Connection to the DUT

Follow the procedure described in “3.3.1 Connecting the Test Leads” (page 20).

5.3.3 Starting the Test and Making Judgments

To start the test:

Move the TIMER switch to the ON position.

Press the START switch when the tester is in the READY state.

When a PASS judgment is made

When the time set by the timer has elapsed, the test voltage is shut off, causing a PASS determination to be returned. The PASS judgment is indicated in three ways: the PASS lamp lights, the buzzer sounds, and a PASS signal is generated.

The PASS state is indicated only briefly (approx. 200 ms), after which the tester immediately enters the READY state.

If a FAIL judgment is returned

If a leakage current exceeding the reference value flows through the DUT during testing, the test voltage is shut off, causing a FAIL determination to be returned. The FAIL judgment is indicated in three ways: the FAIL lamp lights, the buzzer sounds, and a FAIL signal is generated.

The FAIL state is held until the STOP switch is pressed.



To stop the test:

To stop testing (shut off the output) for any reason after testing begins, press the STOP switch.

The following test types are also possible.

It is possible to conduct testing in which the test voltage is gradually increased from 0 V without using the timer. Note that, when setting test voltages of more than 5 mA, testing is subject to output time limitations. For more information, see “Footnote *1” in “9.1 Basic Specifications” (page 46).

Re-application of test voltage (re-testing)

As long as the tester is in a READY state, testing can be repeated under the current test conditions simply by pressing the START switch.

■ Before disconnecting the test leads from the DUT

Confirm that high voltage is not being output, referring to “3.3.3 Checking Safety after Shutting off the Output” (page 23).

Gives the procedure for operating the tester from a remote location using the REMOTE connector and the INTERLOCK terminal.

6.1 Using the REMOTE Connector

Always turn the tester POWER switch off before connecting or disconnecting an optional remote control box or other device to or from the REMOTE connector on the front panel.




Fig. 6-1 REMOTE Connector and POWER Switch

6.1.1 Remote Control with the Optional Remote Control Box

The TOS8030 can be controlled from a remote location using an optional remote control box to start or stop testing.

Connecting the remote control box to the REMOTE connector on the front panel switches the tester from front panel control to remote control. Remote-controlled testing can be started or stopped as shown below:

	Front panel operation	Operations using the remote control box
Start testing	Disabled	START switch
Stop testing	STOP switch	STOP switch

For information on the optional remote control boxes, see “1.3 Options” (page 12).

6.1.2 Remote Control Using a Control Device

The tester can also be operated by remote control using a control device other than one of the listed optional remote control boxes.

⚠ WARNING • Remote control operations involve outputting/shutting down high voltages by external signals. In certain cases, this may entail significant hazards. When high voltages are generated, thorough safety measures are required to prevent inadvertent generation of high voltages and human contact with the DUT, test lead, test probe, or the periphery of the output terminals. Do not operate the tester by remote control unless such measures can be assured.

⚠ CAUTION • Lay the control signal wires apart (more than 500 mm) from the test leads and DUT.

• Never short the test lead to a signal wire. If you do, it may utterly damage the internal circuits of the tester.

Connecting a control device to the front panel's REMOTE connector switches the tester from front panel control to remote control. Remote-controlled testing using a control device is started or stopped as shown below:


	Front panel operation	Operations using a control device
Start testing	Disabled	START signal
Stop testing	STOP switch	STOP signal

For remote control via a control device, the descriptions given for START and STOP switch operations in other chapters (including chapter 5 "Panel Operations") are modified as follows:

Front panel operation	Remote control operations from a control device
Press the START switch.	Input a START signal.
Press the STOP switch.	Input a STOP signal, or press the STOP switch on the front panel.

Connecting a control device to the REMOTE connector requires a 5-pin, DIN Standard-based connector. Contact your Kikusui distributor or agent if you have difficulty obtaining a 5-pin DIN connector.

REMOTE connector pin configuration

	Pin number	Signal name	Description
 <p>Viewed from the panel face</p>	1	RSV	Leave this pin unconnected.
	2	COM	Common terminal
	3	ENABLE	Enables remote control at level L.
	4	START	Testing begins at level L.
	5	STOP	Stops testing at level L.

- The configuration of the REMOTE connector pin numbers are based on DIN Standards. Please note that the pins are not arranged by pin number.

NOTE

- If the REMOTE connector pin 3 is at level L, the tester switches from front panel control to remote control. Configure the control circuits so that pins 2 and 3 connect externally.

Control circuit example




Fig. 6-2 Example: Circuit 1




Fig. 6-3 Example: Circuit 2

Logic elements, transistors, photocouplers, or other elements may take the place of contacts in Fig. 6-2. Fig. 6-3 shows one example.




Fig. 6-4 Example: Circuit 3

REMOTE Connector Input Conditions	
H-level input voltage	11 V to 15 V
L-level input voltage	0 V to 4 V
L-level output-enable current	5 mA or less
Input time width	20 ms minimum

- Each gate is pulled up to +15 V. Opening the input terminals renders a state equivalent to H-level input.
- Consider i and i' so that 5 mA or greater flows through I_c and I_c' .
- To cancel a FAIL state, transmit a STOP signal of at least 20 ms in duration no sooner than 100 ms after the generation of a FAIL signal, as indicated in Fig. 6-5.




Fig. 6-5 Timing of a STOP Signal

Countermeasures against noise

- For elements connected to the tester, using photocouplers as shown in Fig. 6-4 or relays as shown in Fig. 6-3 appears to be advantageous, in that they are capable of reducing the incidence of noise-induced system malfunctions.
- The internal control circuits of the tester has been designed to be resistant against interference by noise generated by the tester and its peripheral devices. However, it is not recommendable to connect non-shielded wires to the pins of the REMOTE connector. Such wires may cause interference to the devices. For the REMOTE connector, cables, and external circuits, use a shielded metallic connector, shielded cables, and external circuits fabricated in a shielded casing. Connect the chassis of the tester to that of the external device. This will isolate the REMOTE connector from the external environments and will become more resistant against noise.

6.2 Using the INTERLOCK Terminal

- ⚠ WARNING** • Short-circuiting the INTERLOCK terminals with the provided jumper is a convenient way to cancel the PROTECTION function, but this jumper should only be used when the tester is being temporarily operated for inspection. For safety, always enable the interlock function when performing actual testing.

To ensure user safety, the TOS8030 interlock function interlocks with external equipment to shut down output. When this function is activated, a PROTECTION state is invoked and output is shut off, preventing further testing. When this function is activated, the PROTECTION state cannot be cancelled simply by pressing the STOP switch on the front panel or by issuing a STOP signal from the remote control.

For improved safety, the interlock function allows testing to be controlled from an external device.

When using the tester, take advantage of the interlock function to improve operational safety. Consider the following examples:

- A cover covering the DUT is provided as an electric shock-prevention device; the status of the interlock function is linked to the opening and closing of the cover.
- Fences are installed around locations where testing is performed; the status of the interlock function is linked to the opening and closing of the fence.

Using the interlock function

Opening the INTERLOCK terminals on the rear panel activates the interlock function. This invokes the PROTECTION state.

To cancel the PROTECTION state invoked by the interlock function, short-circuit the terminals. Press the front panel STOP switch or send a STOP signal from the remote control.




Fig. 6-6 Connecting a Device to the INTERLOCK Terminals

Describes the status signal outputs (SIGNAL OUT).

7.1 Five Signal Outputs

The following status signals are output from the SIGNAL OUT terminals on the rear panel. These signals are output in sync with the states defined in “5.2.1 Five States.” For more information on each state, see “5.2.1 Five States” (page 32).

READY signal	This signal is output when the tester is in a READY state.
H.V ON signal	This signal is output during testing or when high voltage remains in the output terminals (the DANGER lamp remains lit).
PASS signal	This signal is output when the test result is determined to be PASS. A PASS signal is output for approx. 200 ms, after which the tester shifts to a READY state, outputting a READY signal.
FAIL signal	This signal is output when the test result is determined to be FAIL. A FAIL signal is output continuously until the tester enters a READY state or PROTECTION state.
PROTECTION signal	This signal is output when the tester is in a PROTECTION state.

7.2 Using the SIGNAL OUT Terminals

7.2.1 Description of the Terminals

The SIGNAL OUT terminals are circuits in which a contact is closed when a signal is output (make contact signal), and there is no power supply in the internal circuits of SIGNAL OUT terminals. The terminals cannot drive a load without a power supply. See the internal circuit for each pair of terminals shown in Fig. 7-1.




Fig. 7-1 Connecting a Wire to the SIGNAL OUT Terminals

7.2.2 Example: Use of Signals

■ Driving a DC buzzer using a FAIL signal




Fig. 7-2 Example: Use of FAIL Signal

■ Driving a lamp using an H.V ON signal




Fig. 7-3 Example: Use of an H.V ON Signal

■ Obtaining an L-level digital signal at signal output




Fig. 7-4 Conversion into a Logical Signal

In Fig. 7-4, “L”-level output is obtained at point “a” at signal output. However, because a signal at point “a” contains contact chatter, measures for preventing contact chatter are required, which measures are compatible with the subsequent circuit to be connected. Moreover, the minimum applicable load for the contact is 5 V, 10 mA or greater. Thus, set V⁺ and R values so that a load has this rating or above. Other cases may require additional measures against noise.

Describes the maintenance and calibration of the tester. The tester must be periodically inspected, maintained, and calibrated to maintain performance.

8.1 Cleaning the Tester

-
- ⚠ CAUTION**
- Always turn the POWER switch off before cleaning.
 - Do not use volatile solvents such as thinners or benzene. They may discolor the tester surface coating, dissolve printed characters, or cause other problems.
-

If the panel becomes dirty, moisten a piece of soft cloth with a diluted mild detergent and gently wipe the panel.

8.2 Inspection

Power cord

Check that the cover is free of breaks and cracks and that the plug is free of cracks and looseness.

High-voltage test leads

Check that the covering is free of breaks and cracks. Check for broken wires in the test leads using a tester or other device.

-
- ⚠ WARNING**
- A broken wire or breaks or cracking in the wire covering poses the risk of electric shock. If any such defect is observed, immediately stop using the power cord and/or test leads.
-

Please contact your Kikusui distributor or agent to purchase accessories.

8.3 Calibration

The TOS8030 tester is calibrated appropriately on shipment from the factory. However, the tester should be calibrated after long-term usage.

-
- ⚠ WARNING**
- The tester generates voltages as high as 3 kV. Because internal inspection, parts replacement, and calibration is extremely hazardous, all such work should be performed by Kikusui service personnel.
-

Provides the electrical and mechanical specifications for the TOS8030.

The specifications are based on the following conditions and settings, unless otherwise specified.

- Warm-up time: 30 minutes
- Temperature: 5°C to 35°C
- Relative humidity: 20% to 80% (with no dew condensation)
- “xx% of reading” represents xx% of voltmeter reading.

9.1 Basic Specifications

Output section	
Output voltage range	0.05 kV to 3.00 kV/single range
Maximum rated load (*1)	30 VA (3 kV/10 mA) (at a nominal input rating)
Output voltage waveform (*2)	AC line waveform
Voltage regulation	20% or less (during transition from the maximum rated load to no-load)
Switching	A zero-start switch is used.
Voltmeter	
Display	Digital three-digit indication
Measurement range	0.00 kV to 4.00 kV
Display resolution	10 V
Accuracy	± 1.5% FS or Vm ≥ 1.00 kV: ± (5% of reading), Vm < 1.00 kV: ± (5% of reading + 30 V) – whichever is smaller. where FS: full scale (4.00 kV), Vm: measured voltage value
Response	Mean value response/rms value indication

*1 Time limitations on the output

The heat radiation capacity of the output voltage generator section of the tester is designed to be 1/2 of the rated output, in consideration of the instrument dimensions, weight, costs, and other factors. The tester, therefore, must be used under the following time constraints (interval time and output time). If used beyond these limits, the output section may overheat, activating the internal protection circuit. In such cases, always halt testing for a duration equal to or greater than the test duration.

Ambient temperature (t)	Reference value (i)	Interval time	Output time
t ≤ 40°C	5 mA < i ≤ 11 mA	Equal to or greater than output time	10 minutes max.
	i ≤ 5 mA	Not necessary	Continuous output is possible.

*2 Test voltage waveform

If AC voltage is applied to a capacitive load, the output voltage in certain cases may rise above the value at no-load, depending on the value of the capacitive element of the load. Moreover, for samples whose capacitance values show voltage dependency (as with ceramic capacitors), waveform distortions may result. However, for a test voltage of 1.5 kV, the effects of a capacitance of 1000 pF or less may be ignored.

Judgment function	
Judgment method	Compares the reference values and measured leakage current. The result is returned as a PASS or FAIL.
Judgment action	FAIL judgment <ul style="list-style-type: none"> • If a current exceeding the reference value is detected: • The FAIL lamp is lit, • A FAIL signal is output from the SIGNAL OUT terminal (*3), and • The buzzer sounds. (*4)
	PASS judgment <ul style="list-style-type: none"> • When there are no abnormalities even after the set time has elapsed: • The PASS lamp is lit. • A PASS signal is output from the SIGNAL OUT terminal, and • The buzzer sounds. (*4)
Reference value	x0.1 mA range: Can be set from 0.1 mA to 9.9 mA in 0.1 mA steps. x1 mA range: Can be set from 1 mA to 11 mA in 1 mA steps.
Judgment accuracy (*5)	$I_{ref} \geq 1 \text{ mA}: \pm (5\% + 20 \mu\text{A})$ $I_{ref} < 1 \text{ mA}: \pm (5\% + 40 \mu\text{A})$ <div style="text-align: right;">Iref: Reference value</div>
Current detection method	Integrates the absolute current value to compare it to the reference value.
Calibration	Use a pure resistive load to make calibrations based on sine-wave rms values.
Output voltage at no-load that is required for detection (*6)	Approx. 600 V when set to 10 mA
Time	
Test time	x0.1 s range: 0.5 s to 9.9 s, x1 s range: 1 s to 99 s (The TIMER OFF function provided)
Resolution	x0.1 s range: 0.1 s, x1 s range: 1 s
Accuracy	-0 ms, +50 ms

*3 A FAIL signal is continuously output until STOP is input.

*4 The volume of a buzzer can be adjusted. However, it cannot be individually adjusted with respect to FAIL and PASS judgments.

*5 In an AC withstanding voltage test, a current also flows in stray capacities such as measurement leads and devices. The approximate current values flowing in these stray capacities are as shown in the table below.

Output voltage	1 kV	2 kV	3 kV
Main unit only (without measurement leads)	4 μA	8 μA	12 μA
When a lead wire with a length of 350 mm is suspended in air (typical values)	6 μA	12 μA	18 μA
When the provided TL01-TOS lead wires are used (typical values)	20 μA	40 μA	60 μA

*6 Voltage required to make FAIL judgment with the output terminals short-circuited due to internal resistance in the output circuit.


9.2 Other Functions

Remote control		
Connector	5-pin DIN connector on the rear panel	
Control available	Start/stop of testing	
Optional devices connectable	Remote control boxes: RC01-TOS and RC02-TOS High-voltage test probes: HP01A-TOS and HP02A-TOS	
Signal I/O		
Connector	14-pin screw-less terminal on the rear panel	
Status signal output	Output of a READY signal / H.V ON signal / PASS signal / FAIL signal / PROTECTION signal Make-contact signal (contact rating: 1 A/30 Vdc)	
INTERLOCK input terminal	A PROTECTION state is invoked when the terminals are open.	

9.3 General Specifications

Environment		
Operation environment		Indoor use, Overvoltage Category II
Specifications-assured range	Temperature	5°C to 35°C
	Relative humidity	20% to 80% (with no dew condensation)
Operating range	Temperature	0°C to 40°C
	Relative humidity	20% to 80% (with no dew condensation)
Storage range	Temperature	-40°C to 70°C
	Relative humidity	90% or less (with no dew condensation)
Altitude		Up to 2000 m
AC input		
Nominal input rating (Input voltage range)		220 V (200 V to 240 V) or 100 V (90 V to 110 V), 50 Hz or 60 Hz
Power consumption	At no-load (in READY state)	10 VA or less
	At rated load	50 VA maximum
Insulation resistance	AC INPUT to chassis	30 MΩ or more (at 500 Vdc)
Withstand voltage	AC INPUT to chassis	10 mA or less when 1390 Vac is applied for 2 seconds
Earth continuity		25 Aac/0.1 Ω or less
Dimensions (largest section)		160 (170) W x 132 (155) H x 230 (270) D mm
Weight		Approx. 6 kg
Accessories		<ul style="list-style-type: none"> High-voltage test leads TL01-TOS (approx. 1.5 m): 1 set Power cord: 1 INTERLOCK jumper: 1 Operation Manual: 1 copy

9.4 Dimensions



Appendix

Provides guidelines for zero-start switch.

A.1 Improvements in Waveform Obtained Using a Zero-start Switch

In the withstanding voltage tester, opening and closing the primary side of the high voltage transformer with a contact switch opens and closes the primary winding, distorting the output waveform. This results in the application of unnecessarily high voltage to the DUT, potentially damaging the DUT or resulting in a FAIL assessment for a good DUT.

To reduce distortion of test voltage waveforms, the TOS8030 tester uses a zero-start switch semiconductor to open or close a circuit when the supply voltage is near 0 V.




Fig. A-1 Improvements in Waveform Obtained Using the Zero-start Switch

Index

A

AC INPUT 29
accessories 14

B

BUZZER knob 29

C

calibration 45
cleaning 45
current detection upper reference limit 34

D

DANGER lamp 22, 27

E

emergencies 24

F

FAIL judgment 37
FAIL signal 43
FAIL state 32
firmware version 1, 31

G

grounding 18

H

H.V ON signal 43
hazardous operations 2
HIGH VOLTAGE terminal 27
high-voltage test lead 13
high-voltage test probe 13
HP01A-TOS 13
HP02A-TOS 13

I

indicators 27, 31
inspection 45
installation 15
interlock function 42

INTERLOCK terminal 29, 42
interrupting operations 24
interval time 46

L

LOW terminal 27

M

making judgments 37
malfunction event 25
moving 16

O

output time 46

P

PASS judgment 37
PASS signal 43
PASS state 32
power cord 16
POWER switch 26, 30
protection function 33
PROTECTION signal 43
PROTECTION state 32

R

RC01-TOS 12
RC02-TOS 12
READY signal 43
READY state 32
REMOTE connector 38, 40
remote control 38
remote control box 12
re-testing 37
rubber gloves 19

S

SIGNAL OUT terminal 43
START switch 26
starting the test 37
startup inspection 19
status signal output 43
STOP switch 26
stray capacity 47

supply voltage 16

T

test lead 13

- checking 19

- connecting 20

test probe 13

TEST state 32

test time 35

test voltage 35

TEST VOLTAGE knob 28

test voltage waveform 46

time limitations 46

TIMER 28

TL01-TOS 13

TL02-TOS 13

U

upper reference limit 34

V

voltmeter 27

W

window comparator 11

Z

zero-start switch 50

KIKUSUI ELECTRONICS CORP.

1-1-3 Higashiyamata, Tsuzuki-ku, Yokohama, 224-0023, Japan
Tel: +81-45-593-7570 Fax: +81-45-593-7571

Website

<http://www.kikusui.co.jp/en>