

A List of KES4022/KES4022A Messages

コマンド	説明
*CLR	Clear all event registers
*ESR	Queries the event status register
*IDN	Queries the model name
*RST	Initializes all settings except for memory contents and data rate
*SRE	Sets the service request enable register
*STB	Queries the status byte register
CONF:COUNT	Sets the discharge counter mode
CONF:DISP	Sets the display brightness
CONF:GUNTRIG	Sets the gun trigger mode
CONF:VOL1	Sets the volume of the buzzer that sounds upon the completion of a test
CONF:VOL2	Sets the volume of the buzzer that sounds upon an event such as an alarm occurrence
COUNTSET	Sets the discharge count
DSE	Sets the device status enable register
DSR	Queries the device status register
ERR	Queries the error register
HEAD	Sets the header and the unit of measurement
IEC	Sets the IEC test level
INTERVALSET	Sets the discharge interval
MEN	Collectively sets test conditions
MEN:NAME	Sets the user name
MEN:MEMO	Sets the comment
MODE	Sets the discharge mode
OPERATION	Configures the discharge test
POINT	Set the discharge point
POLARITY	Sets the output polarity
RECALL	Recalls memory contents to the panel
SEQUENCESTEP	Sets the step number
SEQUENCESTEPEND	Sets the ending step number
SILENT	Sets whether or not to return acknowledges messages
STARTV	Sets the starting voltage
STEPV	Set the step voltage
STOPV	Sets the stop voltage
STORE	Stores panel settings to memory
TRIGGER	Sets the trigger
VSET	Sets the voltage
WAIT	Sets the wait feature